

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #	Chemistry	Voltage	Capacity	Electrohome Battery Model #
AT&T	1000		NiCd	3.6 V	300 mAh	ETA246
AT&T	1517		NiCd	3.6 V	300 mAh	ETA246
AT&T	1539		NiCd	3.6 V	300 mAh	ETA246
AT&T	2230		NiCd	3.6 V	300 mAh	ETA246
AT&T	2255		NiCd	3.6 V	300 mAh	ETA246
AT&T	2300	3301	NiCd	3.6 V	600 mAh	ETA276
AT&T	2320	3301	NiCd	3.6 V	600 mAh	ETA276
AT&T	2400	V-Tech 5017	NiMH	2.4 V	1500mAh	ETA5017
AT&T	2440	V-Tech 5017	NiMH	2.4 V	1500mAh	ETA5017
AT&T	2455	V-Tech 5017	NiMH	2.4 V	1500mAh	ETA5017
AT&T	3000		NiCd	3.6 V	300 mAh	ETA246
AT&T	3400		NiCd	3.6 V	300 mAh	ETA246
AT&T	3410		NiCd	3.6 V	300 mAh	ETA246
AT&T	4000		NiCd	3.6 V	300 mAh	ETA246
AT&T	4100		NiCd	3.6 V	300 mAh	ETA246
AT&T	4110		NiCd	3.6 V	300 mAh	ETA246
AT&T	4126		NiCd	3.6 V	1000 mAh	ETA288
AT&T	4200		NiCd	3.6 V	300 mAh	ETA246
AT&T	4210		NiCd	3.6 V	300 mAh	ETA246
AT&T	4300		NiCd	3.6 V	300 mAh	ETA246
AT&T	4305		NiCd	3.6 V	300 mAh	ETA246
AT&T	4310		NiCd	3.6 V	300 mAh	ETA246
AT&T	4315		NiCd	3.6 V	300 mAh	ETA246
AT&T	4320		NiCd	3.6 V	300 mAh	ETA246
AT&T	4335		NiCd	3.6 V	300 mAh	ETA246
AT&T	4400		NiCd	3.6 V	300 mAh	ETA246
AT&T	4410		NiCd	3.6 V	300 mAh	ETA246
AT&T	4500		NiCd	3.6 V	300 mAh	ETA246
AT&T	4600		NiCd	3.6 V	300 mAh	ETA246
AT&T	4615		NiCd	3.6 V	300 mAh	ETA246
AT&T	4800		NiCd	3.6 V	300 mAh	ETA246
AT&T	4810		NiCd	3.6 V	300 mAh	ETA246
AT&T	5200		NiCd	3.6 V	300 mAh	ETA246
AT&T	5210		NiCd	3.6 V	300 mAh	ETA246
AT&T	5300		NiCd	3.6 V	300 mAh	ETA246
AT&T	5310		NiCd	3.6 V	300 mAh	ETA246
AT&T	5320		NiCd	3.6 V	300 mAh	ETA246
AT&T	5352		NiCd	3.6 V	300 mAh	ETA246
AT&T	5400		NiCd	3.6 V	300 mAh	ETA246
AT&T	5402		NiCd	3.6 V	300 mAh	ETA246
AT&T	5450		NiCd	3.6 V	300 mAh	ETA246
AT&T	5470		NiCd	3.6 V	300 mAh	ETA246
AT&T	5500		NiCd	3.6 V	300 mAh	ETA246
AT&T	5515		NiCd	3.6 V	300 mAh	ETA246
AT&T	5600		NiCd	3.6 V	300 mAh	ETA246
AT&T	6600		NiCd	3.6 V	300 mAh	ETA246
AT&T	9311		NiCd	3.6 V	600 mAh	ETA276
AT&T	9351		NiCd	3.6 V	600 mAh	ETA276
AT&T	9355		NiCd	3.6 V	600 mAh	ETA276
AT&T	9410		NiCd	3.6 V	600 mAh	ETA276
AT&T	HT-2231	2419	NiCd	3.6V	700 mAh	ETA247
AT&T	HT-3400		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-4100		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-4200		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-4210		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-4400		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-4410		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-5200		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-5210		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-5300		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-5310		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-5320		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-5500		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-6000		NiCd	3.6 V	300 mAh	ETA246
AT&T	HT-7000		NiCd	3.6 V	300 mAh	ETA246
AT&T	Merlin MCL-5		NiCd	3.6 V	300 mAh	ETA246
AT&T	Normad 3000		NiCd	3.6 V	300 mAh	ETA246
AT&T	Normad 4000A		NiCd	3.6 V	300 mAh	ETA246
Audiovox	DST-961		NiCd	3.6 V	600 mAh	ETA272
Audiovox	DT-911		NiCd	3.6 V	600 mAh	ETA272
Audiovox	DT-921		NiCd	3.6 V	600 mAh	ETA272
Audiovox	DT-931		NiCd	3.6 V	600 mAh	ETA272
Audiovox	DT-941		NiCd	3.6 V	600 mAh	ETA272
Audiovox	DT-951		NiCd	3.6 V	600 mAh	ETA272
Bell South	9915		NiCd	3.6 V	600 mAh	ETA275
Bell South	MH-9012		NiCd	3.6 V	600 mAh	ETA275
Bell South	MH-9934BK		NiCd	3.6 V	600 mAh	ETA275
Casio	CP1218	BT905	NiCd	3.6 V	600 mAh	ETA277
Casio	CP1240	BT905	NiCd	3.6 V	600 mAh	ETA277
Casio	CP530	3210101	NiCd	3.6 V	300 mAh	ETA246
Casio	TC510	3210101	NiCd	3.6 V	300 mAh	ETA246

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #	Chemistry	Voltage	Capacity	Electrohome Battery Model #
Casio	TC540	3210101	NiCd	3.6 V	300 mAh	ETA246
Casio	TC725	3210101	NiCd	3.6 V	300 mAh	ETA246
Casio	TC920		NiCd	3.6 V	600 mAh	ETA276
Cicero	CT205	BT905	NiCd	3.6V	600mAh	ETA277
Cicero	CT206	BT905	NiCd	3.6V	600mAh	ETA277
Citizen	2001	BT905	NiCd	3.6 V	600 mAh	ETA277
Citizen	2005	BT905	NiCd	3.6 V	600 mAh	ETA277
Cobra	213-001-9-001		NiCd	3.6 V	600 mAh	ETA275
Cobra	213-0090-9001		NiCd	3.6 V	600 mAh	ETA275
Cobra	213-009-9001		NiCd	3.6 V	600 mAh	ETA275
Cobra	213-010-9-001		NiCd	3.6 V	600 mAh	ETA275
Cobra	213-021-N-001		NiCd	3.6 V	600 mAh	ETA277
Cobra	523-548-9-001		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP100SA		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP110		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP110SA		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP115S		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP115SA		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP120		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP120SA		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP130		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP130SA		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP140		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP140R		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP140S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP140SA		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP205SA		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP210		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP210RA		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP210S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP220		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP220S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP220S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP250CM		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP250S		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP301S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP302		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP302S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP310		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP310S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP320		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP320S		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP330		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP355		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP355S		NiCd	3.6 V	600 mAh	ETA277
Cobra	CP440		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP440S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP443		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP443S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP445		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP445S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP447		NiCd	3.6 V	300 mAh	ETA275
Cobra	CP-447S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP450		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP450S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP460		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP460S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP464		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP464S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP468		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP468S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP469		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP469S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP470		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP470S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP471		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP471S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP472		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP472S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP473		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP473S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP474		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP474S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP475		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP475S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP477S		NiCd	3.6 V	600 mAh	ETA275
Cobra	CP478	3N270AA	NiCd	3.6 V	300 mAh	ETA242
Cobra	CP478S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP481		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP482		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP482S		NiCd	3.6 V	300 mAh	ETA242

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #	Chemistry	Voltage	Capacity	Electrohome Battery Model #
Cobra	CP483		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP483S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP484		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP484S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP485S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP486		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP487		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP488		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP489		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP489S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP490		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP490-10		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP482		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP701		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP702		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP703		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP705		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP705S		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP711		NiCd	3.6 V	300 mAh	ETA242
Cobra	CP712		NiCd	3.6 V	300 mAh	ETA242
Direct Pwr Plus	USOM		NiCd	3.6 V	300 mAh	ETA242
Dynacharge	NC-T2/3AW		NiCd	3.6 V	300 mAh	ETA242
Dynacharge	NC-T920		NiCd	3.6 V	600 mAh	ETA275
Dynacharge	NC-TAW		NiCd	3.6 V	600 mAh	ETA275
Empire	CPB-400B		NiCd	3.6 V	600 mAh	ETA277
GE	2-6700	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-6730	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-6920	BT31	NiCd	3.6 V	600 mAh	ETA276
GE	2-6921	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-6922	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-6928	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-6930	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-6936	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-6938	5-2461	NiCd	3.6 V	600 mAh	ETA276
GE	2-6980	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-6990	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-6993	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-7000	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-7700	GETL96158	NiMH	3.6 V	600mAh	ETA596
GE	2-7730	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-7910	GETL96158	NiMH	3.6 V	600mAh	ETA596
GE	2-7920	GETL96158	NiMH	3.6 V	600mAh	ETA596
GE	2-7930	GETL96158	NiMH	3.6 V	600mAh	ETA596
GE	2-7936	5-2522	NiMH	3.6 V	600mAh	ETA596
GE	2-7939	GETL96158	NiMH	3.6 V	600mAh	ETA596
GE	2-7993	5-2522	NiMH	3.6 V	600mAh	ETA596
GE	2-9512	BT10	NiCd	3.6 V	300 mAh	ETA242
GE	2-9515	BT10	NiCd	3.6 V	300 mAh	ETA242
GE	2-9530	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9582	BT10	NiCd	3.6 V	300 mAh	ETA242
GE	2-9613	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9614	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9615	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9616	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9625	BT10	NiCd	3.6 V	300 mAh	ETA242
GE	2-9626	BT10	NiCd	3.6 V	300 mAh	ETA242
GE	2-9632	BT10	NiCd	3.6 V	300 mAh	ETA242
GE	2-9632	BT11	NiCd	3.6 V	300 mAh	ETA248
GE	2-9635	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9638	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9645	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9646	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9740	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9750	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9753	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9755	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9770	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9772	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9775	BT12	NiCd	3.6 V	300 mAh	ETA246
GE	2-9790	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-9917	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-9918	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-9920	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-9930	BT31	NiCd	3.6 V	600 mAh	ETA275
GE	2-1006GE3	5-2459	NiCd	3.6 V	600 mAh	ETA276
GE	2-29256E2		NiCd	3.6 V	600 mAh	ETA275
GE	2-6920GE1	BT31	NiCd	3.6 V	600 mAh	ETA276
GE	2-6920GE2	BT31	NiCd	3.6 V	600 mAh	ETA276
GE	2-6928GE1	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-6928GE2	BT16	NiCd	3.6 V	600 mAh	ETA276
GE	2-6930GE1	BT16	NiCd	3.6 V	600 mAh	ETA276

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
GE	2-6938GE1	5-2461	NiCd	3.6 V	600 mAh		ETA276
GE	2-6938GE2	5-2461	NiCd	3.6 V	600 mAh		ETA276
GE	2-6955GE1	5-2459	NiCd	3.6 V	600 mAh		ETA276
GE	2-6992GE1	BT16	NiCd	3.6 V	600 mAh		ETA276
GE	2-6993GE1	BT16	NiCd	3.6 V	600 mAh		ETA276
GE	2-6998GE1	BT16	NiCd	3.6 V	600 mAh		ETA276
GE	2-6998GE2	BT16	NiCd	3.6 V	600 mAh		ETA276
GE	2-7000GE2	BT16	NiCd	3.6 V	600 mAh		ETA276
GE	2-7730GE2	BT31	NiCd	3.6 V	600 mAh		ETA275
GE	2-7928GE1	BT16	NiCd	3.6 V	600 mAh		ETA276
GE	2-7930GE3	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7930GE4	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7930GE5	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7930GE6	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7930GE7	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7935GE1	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7935GE3	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7990GE3	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-7993GE3	GETL96158	NiMH	3.6 V	600mAh		ETA596
GE	2-9585A	BT12	NiCd	3.6 V	300 mAh		ETA246
GE	2-9752A	BT12	NiCd	3.6 V	300 mAh		ETA246
GE	2-9775A	BT12	NiCd	3.6 V	300 mAh		ETA246
GE	2-9920A	BT31	NiCd	3.6 V	600 mAh		ETA275
GE	7936GE1	GETL96158	NiMH	3.6 V	600mAh		ETA596
Goldstar	2000CT	BT12	NiCd	3.6 V	300 mAh		ETA246
Goldstar	200CT	BT12	NiCd	3.6 V	300 mAh		ETA246
Goldstar	20X	BT12	NiCd	3.6 V	300 mAh		ETA246
Goldstar	Circa 2000	BT12	NiCd	3.6 V	300 mAh		ETA246
IBM	3455	GP60AAS3BMJ	NiCd	3.6 V	600 mAh		ETA276
ITT	3310		NiCd	3.6 V	600 mAh		ETA275
Motorola	MA300	AA600BX3	NiCd	3.6 V	600 mAh		ETA276
Motorola	MA351	AA600BX3	NiCd	3.6 V	600 mAh		ETA276
Motorola	MA451	AA600BX3	NiCd	3.6 V	600 mAh		ETA276
Motorola	MA471	AA600BX3	NiCd	3.6 V	600 mAh		ETA276
Motorola	MD41	AA600BX3	NiCd	3.6 V	600 mAh		ETA276
Nippon	3000		NiCd	3.6 V	300 mAh		ETA246
N'Western Bell	255		NiCd	3.6 V	600 mAh		ETA277
N'Western Bell	39205-1		NiCd	3.6 V	300 mAh		ETA242
N'Western Bell	39205-4		NiCd	3.6 V	300 mAh		ETA242
N'Western Bell	39230-4		NiCd	3.6 V	300 mAh		ETA242
N'Western Bell	39300-2		NiCd	3.6 V	300 mAh		ETA242
N'Western Bell	39605-4		NiCd	3.6 V	300 mAh		ETA242
N'Western Bell	39705-4		NiCd	3.6 V	300 mAh		ETA242
N'Western Bell	39765-4		NiCd	3.6 V	300 mAh		ETA242
N'Western Bell	Excursion 32011		NiCd	3.6 V	600 mAh		ETA277
Pacific Bell	800		NiCd	3.6 V	300 mAh		ETA246
Pacific Bell	810		NiCd	3.6 V	300 mAh		ETA246
Pacific Bell	820		NiCd	3.6 V	300 mAh		ETA246
Pactel	2282504		NiCd	3.6 V	300 mAh		ETA246
Pactel	CS-8000		NiCd	3.6 V	300 mAh		ETA246
Pactel	CS-8100		NiCd	3.6 V	300 mAh		ETA246
Pactel	CS-8200		NiCd	3.6 V	300 mAh		ETA246
Pactel	CS-8400		NiCd	3.6 V	300 mAh		ETA246
Pactel	CS-8410		NiCd	3.6 V	300 mAh		ETA246
Panasonic		P-P303PA	NiCd	3.6 V	300 mAh		ETA246
Panasonic	HHR-P401A		NiMH	3.6 V	1150 mAh		ETA578
Panasonic	KC-TCC106C	HHR-P401	NiMH	3.6 V	1150 mAh		ETA578
Panasonic	KX-A36	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-A36A	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-A43	P-P543PA	NiCd	3.6 V	600 mAh		ETA263 *
Panasonic	KX-T187	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3260	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3610	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3611	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3620	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3640	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3702	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3705	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3710	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3712	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3720	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3725	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3730	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3732	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3800	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3805	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3807	P-P301	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3815	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3823	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-T3824	P-P301PA	NiCd	3.6 V	300 mAh		ETA248

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #	Chemistry	Voltage	Capacity	Electrohome Battery Model #
Panasonic	KX-T3825	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T3832	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T3835	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T3838	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3842	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T3845	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T3848	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3850	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3855	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3860	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3870	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3875	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3878	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3880	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3880R	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T38SSR	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3900R	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T3908	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3910	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3912	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3920	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3925	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3930	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3932	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3935	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3940	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3945	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3950	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3960	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3962	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3965	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3967	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3968	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T3980	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4000	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4008	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4035	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4050	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4068	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4108	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4109	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4168	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4169	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4200	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4300	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4310	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4330	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4340	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4340	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4342	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4350	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4350R	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4360	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4365	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4370	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4400	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4400	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4410	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4500	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4550	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T4600	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T6168	P-P301PA	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-T815	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-T900	P-P543PA	NiCd	3.6 V	600 mAh	ETA263 **
Panasonic	KX-T9500	P-P543PA	NiCd	3.6 V	600 mAh	ETA263 **
Panasonic	KX-T9500C	P-P543PA	NiCd	3.6 V	600 mAh	ETA263 **
Panasonic	KX-T9505	P-P543PA	NiCd	3.6 V	600 mAh	ETA263 **
Panasonic	KX-T9509	P-P543PA	NiCd	3.6 V	600 mAh	ETA263 **
Panasonic	KX-T9520	P-P543PA	NiCd	3.6 V	600 mAh	ETA263 **
Panasonic	KX-T9550	P-P543PA	NiCd	3.6 V	600 mAh	ETA263 **
Panasonic	KX-TC100	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-TC109	P-P301	NiCd	3.6 V	300 mAh	ETA248
Panasonic	KX-TC1400	P-P501	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-TC1401W	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-TC1405	P-P501PA	NiCd	3.6 V	600 mAh	ETA277
Panasonic	KX-TC1408	P-P501PA	NiCd	3.6 V	600 mAh	ETA277

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
Panasonic	KX-TC1450	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1484	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1493	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1493B	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1493WH	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC150	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1500	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1501W	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1503	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1503B	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC155	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC157	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC160	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC160C	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC162B	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC163	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC165	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC165C	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1700	P-P501	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1701B	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1703	P-P501	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1703B	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1710	P-P501	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1721	P-P501	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1731B	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1740	P-P501	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1741B	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1743	P-P501	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC180	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1800	P-P501	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1801	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC1801B	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC180C	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1811B	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC183	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1831	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC1831W	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC183C	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC185	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1851	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC1851C	P-P501PA	NiCd	3.6 V	600 mAh		ETA277
Panasonic	KX-TC1861B	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC1866B	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC187	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1871	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC187C	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC1886B	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC1891B	P-P508	NiCd	3.6 V	1000 mAh		ETA288
Panasonic	KX-TC190	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC280	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC280C	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC289	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC900	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC900B	P-P592PA	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC900C	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC900W	P-P592PA	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC905	P-P543PA	NiCd	3.6 V	600 mAh		ETA263 **
Panasonic	KX-TC909	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC910	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC910B	P-P592PA	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC910C	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC910DB	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC914	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC919	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC919B	P-P592PA	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC930	P-P543	NiCd	3.6 V	600 mAh		ETA263 **
Panasonic	KX-TC940	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC940B	P-P592PA	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC940W	P-P592PA	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC9500	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC9500C	P-P592	NiCd	3.6 V	600 mAh		ETA271 **
Panasonic	KX-TC9509	P-P543	NiCd	3.6 V	600 mAh		ETA263 **
Panasonic	KX-TC9520	P-P543	NiCd	3.6 V	600 mAh		ETA263 **
Panasonic	KX-TC9550	P-P301PA	NiCd	3.6 V	300 mAh		ETA248
Panasonic	KX-TC970	P-P301PA	NiCd	3.6 V	300 mAh		ETA248

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
Panasonic	KX-TC970W	P-P592PA	NiCd		3.6 V	600 mAh	ETA271 **
Panasonic	KX-TCA14	P-P501PA	NiCd		3.6 V	600 mAh	ETA277
Panasonic	KX-TCA92	P-P592PA	NiCd		3.6 V	600 mAh	ETA271 **
Panasonic	KX-TCC106	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCC106C	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCC116	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCC116	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCC902	P-P592PA	NiCd		3.6 V	600 mAh	ETA271 **
Panasonic	KX-TCC902	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCC912	P-P592PA	NiCd		3.6 V	600 mAh	ETA271 **
Panasonic	KX-TCC942	P-P592PA	NiCd		3.6 V	600 mAh	ETA271 **
Panasonic	KX-TCM415	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCM415	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCM415C	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCM415C	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCM4169	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCM4169	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCM418	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCM420	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCM422	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCS970	P-P592PA	NiCd		3.6 V	600 mAh	ETA271 **
Panasonic	KX-TCT4169C	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCT4169C	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TCT4310	P-P301PA	NiCd		3.6 V	300 mAh	ETA248
Panasonic	KX-TCT4310	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KXTG1000N	HHR-P546PA	NiMH		2.4 V	1500mAh	ETA5017
Panasonic	KXTG1050N	HHR-P546PA	NiMH		2.4 V	1500mAh	ETA5017
Panasonic	KX-TG200ALB	HHR-P505PA	NiMH		3.6V	1000mAH	ETA288
Panasonic	KX-TG200CB	HHR-P505PA	NiMH		3.6V	1000mAH	ETA288
Panasonic	KX-TG210ALB	HHR-P505PA	NiMH		3.6V	1000mAH	ETA288
Panasonic	KX-TG2205	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2208	HHR-P513	NiMH		2.4V	1500mAh	ETA513 **
Panasonic	KX-TG2214	HHR-P513	NiMH		2.4V	1500mAh	ETA513 **
Panasonic	KX-TG2215	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2216	HHR-P513	NiMH		2.4V	1500mAh	ETA513 **
Panasonic	KX-TG2217	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2222	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2224	HHR-P513	NiMH		2.4V	1500mAh	ETA513 **
Panasonic	KX-TG2237	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2238	HHR-P513	NiMH		2.4V	1500mAh	ETA513 **
Panasonic	KX-TG2247	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2257	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2267	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2287	P-P511A	NiMH		3.6V	1500mAh	ETA511
Panasonic	KX-TG2396	HHR-P401	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TG2397	HHR-P401	NiMH		3.6V	1150 mAh	ETA578
Panasonic	KX-TG2400	HHR-P401	NiMH		3.6V	1150mAh	ETA578
Panasonic	KX-TG2403	P-P510A	NiMH		3.6V	1000mAh	ETA288
Panasonic	KX-TG2405	HHR-P401	NiMH		3.6V	1150mAh	ETA578
Panasonic	KX-TG2411		NiMH		2.4V	900mAh	ETA505
Panasonic	KX-TG2421F		NiMH		2.4V	900mAh	ETA505
Panasonic	KX-TG2421P		NiMH		2.4V	900mAh	ETA505
Panasonic	KX-TG2424		NiMH		2.4V	900mAh	ETA505
Panasonic	KX-TG2431		NiMH		2.4V	900mAh	ETA505
Panasonic	KX-TG2480S	HHR-P104	NiMH		2.4V	830mAh	ETA504 **
Panasonic	KX-TG2500	HHR-P401	NiMH		3.6V	1150mAh	ETA578
Panasonic	KX-TG2500S	HHR-P401A	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TG2550	HHR-P401	NiMH		3.6V	1150mAh	ETA578
Panasonic	KX-TG2551	P-P510A	NiMH		3.6V	1000mah	ETA288
Panasonic	KX-TG2553	P-P510A	NiMH		3.6V	1000mAh	ETA288
Panasonic	KX-TG2560	HHR-P401A	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TG2560B	HHR-P401A	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TG2563	P-P510A	NiMH		3.6V	1000mAh	ETA288
Panasonic	KX-TG2564	P-P510A	NiMH		3.6V	1000mah	ETA288
Panasonic	KX-TG2570	HHR-P401	NiMH		3.6V	1150mAh	ETA578
Panasonic	KX-TG2570S	HHR-P401A	NiMH		3.6 V	1150 mAh	ETA578
Panasonic	KX-TG2575	HHR-P401	NiMH		3.6V	1150mAh	ETA578
Panasonic	KX-TG2583	P-P510A	NiMH		3.6V	1000mAh	ETA288
Panasonic	KX-TG2584	P-P510A	NiMH		3.6V	1000mAh	ETA288
Panasonic	KX-TG2593	P-P510A	NiMH		3.6V	1000mAh	ETA288
Panasonic	KX-TG2650	P-509A	NiMH		2.4 V	1500mAh	ETA509 **
Panasonic	KX-TG2650N	P-509A	NiMH		2.4 V	1500mAh	ETA509 **
Panasonic	KX-TG2670N	P-509A	NiMH		2.4 V	1500mAh	ETA509 **
Panasonic	KX-TG2680	P-509A	NiMH		2.4 V	1500mAh	ETA509 **
Panasonic	KX-TG2690	P-509A	NiMH		2.4 V	1500mAh	ETA509 **

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
Panasonic	KX-TG2730	P-P511A	NiMH	3.6V	1500mAh		ETA511
Panasonic	KX-TG2770	P-P511A	NiMH	3.6V	1500mAh		ETA511
Panasonic	KX-TG5100	P-P511A	NiMH	3.6V	1500mAh		ETA511
Panasonic	KX-TG5421S	HHRP104	NiMH	3.6V	850mAh		ETA504 **
Panasonic	KX-TG5422M	HHRP104	NiMH	3.6V	850mAh		ETA504 **
Panasonic	KX-TG5431S	HHRP104	NiMH	3.6V	850mAh		ETA504 **
Panasonic	KX-TG5432M	HHRP104	NiMH	3.6V	850mAh		ETA504 **
Panasonic	KX-TGA100N	HHR-P546PA	NiMH	2.4 V	1500mAh		ETA5017
Panasonic	KX-TGA2705	P-P511A	NiMH	3.6V	1500mAh		ETA511
Panasonic	KX-TGM240B	HHR-P505PA	NiMH	3.6V	1000mAh		ETA288
Panasonic	TX-T3800		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3805		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3815		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3823		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3824		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3850		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3860		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3880		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3910		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3920		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3960		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T3980		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T4200		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T4300		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T4350		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T4350R		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T4370		NiCd	3.6 V	300 mAh		ETA248
Panasonic	TX-T4400		NiCd	3.6 V	300 mAh		ETA248
Panasonic		P-P303	NiCd	3.6 V	300 mAh		ETA246
Philips	TD9213		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9240		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9241		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9242		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9245		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9246		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9273		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9603		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9614		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9673		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9841		NiCd	3.6 V	300 mAh		ETA246
Philips	TD9844		NiCd	3.6 V	300 mAh		ETA246
PhoneMate	PMP3850	PM-38BAT	NiMH	3.6 V	600mAh		ETA538 **
PhoneMate	PMP38560	PM-38BAT	NiMH	3.6 V	600mAh		ETA538 **
PhoneMate	PMP3875	PM-38BAT	NiMH	3.6 V	600mAh		ETA538 **
RadioShack	43-1128	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-1129	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-1130	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-1702	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-1703	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-3512	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-3807	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-3810	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-564	23-281	NiCd	3.6 V	300 mAh		ETA248
RadioShack	43-681	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-683	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-684	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-686	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-725	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-729	23-193	NiCd	3.6 V	600 mAh		ETA277
RadioShack	43-734	23-193	NiCd	3.6 V	600 mAh		ETA277
Sanyo	16743	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS1200	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS125	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS130	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS1300	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS13600	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS1500	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS160	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS170	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS1700	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS300	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS8371	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CAS8871	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-1300	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-1561	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
Sanyo	CLT-1581	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-1761	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-1861	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-1881	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-2410	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2410A	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2410S	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2415	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2420	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2422	GES3AHRAACL	NiCd	3.6 V	600 mAh		ETA596
Sanyo	CLT-2430	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2430S	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2435S	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-2761	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-30	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-3100	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-3200	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-3300	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-3600	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-4300	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-4360	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-4450	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-4600	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-4650	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-520	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-5561	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-5600	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-5761	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-580	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-5861	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-6100	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-6300	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-6450	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-6571	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-6750	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-7100	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8205	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8371	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8500	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8600	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8601	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8800	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA248
Sanyo	CLT-8801	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8809	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-8871	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-9081	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9100	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9109	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9171	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9181	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9200	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-9261	GES-PCH-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT927	GES-PCH-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9400	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-9500	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CLT-9571	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9581	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT966	GES-PCH-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9661	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9810	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9812	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9819	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9839	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9861	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9901	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9902	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9902B	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9903	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9904B	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9905	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9920	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9920C	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9930	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9930C	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9950	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
Sanyo	CLT-9950C	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9960	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-9965C	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-A901	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLT-A9011	GES-PCF-01	NiCd	3.6 V	600 mAh		ETA275
Sanyo	CLYT-33	GES-PCH-01	NiCd	3.6 V	300 mAh		ETA242
Sanyo	CP-3F01		NiCd	3.6 V	600 mAh		ETA275
Sanyo	GES-PCF01		NiCd	3.6 V	600 mAh		ETA275
Sanyo	H02		NiCd	3.6 V	300 mAh		ETA248
Sanyo	PCF01		NiCd	3.6 V	600 mAh		ETA275
Sears	34953		NiCd	3.6 V	300 mAh		ETA246
Sears	34955		NiCd	3.6 V	300 mAh		ETA246
Sears	34965		NiCd	3.6 V	300 mAh		ETA246
Sony	SPP-116	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-121	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-15	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-160	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-180	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-206	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-320	BP-T40	NiCd	4.0 V	500 mAh		ETA250
Sony	SPP-400	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-5100	BP-T40	NiCd	4.0 V	500 mAh		ETA250
Sony	SPP-57	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-60	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-72	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-75		SLA	4.0 V	500 mAh		ETA250
Sony	SPP-77	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-85	BP-T40	NiCd	4.0 V	500 mAh		ETA250
Sony	SPP-910		NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-930	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-933		NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-934	BP-T18	NiCd	3.6 V	600 mAh		ETA277
Sony	SPP-936	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-95	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-97	BP-T40	SLA	4.0 V	500 mAh		ETA250
Sony	SPP-A11	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A20	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A40	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A400	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A50	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A57	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A700	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A9171	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-A941	BP-T31	NiCd	3.6 V	600 mAh		ETA263 **
Sony	SPP-A946	BP-T18	NiCd	3.6 V	600 mAh		ETA277
Sony	SPP-A968	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-A974	BP-T24	NiMH	3.6 V	1150 mAh		ETA578
Sony	SPP-A985		NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-D900	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-ID300	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-ID400	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-ID700	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-ID910	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-ID930	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-ID971	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-ID976	BP-T23	NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-IM977		NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-IM982		NiCd	3.6 V	600 mAh		ETA272
Sony	SPP-N1001	BP-T50	NiCd	2.4 V	600 mAh		ETA279 **
Sony	SPP-N1021	BP-T50	NiCd	2.4 V	600 mAh		ETA279 **
Sony	SPP-N1026	BP-T50	NiCd	2.4 V	600 mAh		ETA279 **
Sony	SPP-Q110	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-Q120	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-Q150	BP-T16	NiCd	3.6 V	300 mAh		ETA248
Sony	SPP-S9001	BP-T31	NiCd	3.6 V	600 mAh		ETA263 **
Sony	SPP-S9101	BP-T31	NiCd	3.6 V	600 mAh		ETA263 **
Sony	SPP-S9226	BP-T24	NiMH	3.6 V	1150 mAh		ETA578
Sony	SPP-X9001	BP-T40	SLA	4.0 V	500mAh		ETA250
S'Western Bell	FF-1150		NiCd	3.6 V	300 mAh		ETA248
S'Western Bell	FF-1175		NiCd	3.6 V	300 mAh		ETA248
S'Western Bell	FF-1700		NiCd	3.6 V	300 mAh		ETA248
S'Western Bell	FF-1725		NiCd	3.6 V	300 mAh		ETA248
S'Western Bell	FF-1750		NiCd	3.6 V	300 mAh		ETA248
S'Western Bell	FF-650		NiCd	3.6 V	300 mAh		ETA248
S'Western Bell	FF-675		NiCd	3.6 V	300 mAh		ETA248

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #	Chemistry	Voltage	Capacity	Electrohome Battery Model #
S'Western Bell	FF-700		NiCd	3.6 V	300 mAh	ETA248
S'Western Bell	FF-905		NiCd	3.6 V	600 mAh	ETA275
S'Western Bell	FF-908		NiCd	3.6 V	600 mAh	ETA275
S'Western Bell	FF-915		NiCd	3.6 V	600 mAh	ETA275
S'Western Bell	FF-925		NiCd	3.6 V	600 mAh	ETA275
Telepower	TF/3AAAT-W		NiCd	3.6 V	600 mAh	ETA275
Toshiba	FD-9859BK		NiCd	3.6 V	600 mAh	ETA277
Toshiba	FT-6003		NiCd	3.6 V	300 mAh	ETA248
Toshiba	FT-6005		NiCd	3.6 V	300 mAh	ETA242
Toshiba	FT-6203		NiCd	3.6 V	300 mAh	ETA242
Toshiba	FT-6503		NiCd	3.6 V	300 mAh	ETA242
Toshiba	FT-6603		NiCd	3.6 V	300 mAh	ETA242
Toshiba	FT-7106		NiCd	3.6 V	300 mAh	ETA242
Toshiba	FT-8000		NiCd	3.6 V	600 mAh	ETA277
Toshiba	FT-8006		NiCd	3.6 V	300 mAh	ETA242
Toshiba	FT-8009		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8258BK		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8505BK		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8508BK		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8808BK		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8809		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-888		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8908		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8930		NiCd	3.6 V	600 mAh	ETA277
Toshiba	FT-8958BK		NiCd	3.6 V	600 mAh	ETA274
Toshiba	FT-8980		NiCd	3.6 V	600 mAh	ETA277
Toshiba	FT-8981		NiCd	3.6 V	600 mAh	ETA277
Toshiba	SG-1700		NiCd	3.6 V	600 mAh	ETA277
Toshiba	SX2258		NiCd	3.6 V	600 mAh	ETA274
Toshiba	SX2800		NiCd	3.6 V	600 mAh	ETA277
Toshiba	SX2808BK		NiCd	3.6 V	600 mAh	ETA274
Toshiba	SX2930		NiCd	3.6 V	600 mAh	ETA277
Toshiba	SX2980		NiCd	3.6 V	600 mAh	ETA277
Uniden	AE-255		NiCd	3.6 V	600 mAh	ETA277
Uniden	AM-468V	BT185	NiCd	3.6 V	300 mAh	ETA248
Uniden	AM46EV		NiCd	3.6 V	300 mAh	ETA248
Uniden	AM-46EV	BT185	NiCd	3.6 V	300 mAh	ETA248
Uniden	BT-999		NiCd	3.6 V	600 mAh	ETA272
Uniden	CT-301	BT185	NiCd	3.6 V	300 mAh	ETA248
Uniden	DX-8200	BT185	NiCd	3.6 V	300 mAh	ETA248
Uniden	DX834	BT185	NiCd	3.6 V	300 mAh	ETA248
Uniden	DXAI388-2	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	DXI3286	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	DXI386-2	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	DXI665	BT185	NiCd	3.6 V	300 mAh	ETA248
Uniden	DXI665S	BT185	NiCd	3.6 V	300 mAh	ETA248
Uniden	ESX2050	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EX17960	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EX2100		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX3100		NiCd	3.6 V	600 mAh	ETA275
Uniden	EX3101		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX3102		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX3182		NiCd	3.6 V	600 mAh	ETA275
Uniden	EX3800		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX3810		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX4100		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX4101		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX4102		NiCd	3.6 V	600 mAh	ETA277
Uniden	EX4800		NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA13248A	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA1915	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA1918	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA2245	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA2850	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA2950	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA2955	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA3245	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA3955	BT905	NiCd	3.6V	600 mAh	ETA277
Uniden	EXA6950	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA7950	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXA8955	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXAI2246	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXAI2248	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXAI2248i	BT905	NiCd	3.6 V	600 mAh	ETA277
Uniden	EXAI2980	BT905	NiCd	3.6 V	600 mAh	ETA277

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
Uniden	EXAI2980HS	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXAI2980I	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXAI378	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXAI378I	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXAI3985	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXAI6980	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI2246	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI2926	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI2926A	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI2926HS	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI2960	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI2965	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI376	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI376A	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI376CA	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI376HS	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI378A	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI3965	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI6960	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI7926HS	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI7960	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI7960	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI8965	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI8965	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI8966	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXI8966	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXL8900	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXL8901	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXL8945	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXL8950	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXL8962	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2240	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2240A	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2241	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2243	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2800	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2900	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2901	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP2903	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP3240A	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP6900	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP7000	BT990	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXP7900	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP7901	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP7902	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP7903	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP7904C	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP7904L	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP7904T	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP920	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXP990		NiCd	3.6 V	800 mAh		ETA274
Uniden	EXR2460	BT2499	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXR2480	BT2499	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS2010	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXS2050	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXS2060	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXS9005	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXS9110	BT990	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS9500	BT990	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS9600	BT990	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS9650	BT990	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS9660	BT990	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS9800	BT990	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS9910	BT999	NiCd	3.6 V	600 mAh		ETA272
Uniden	EXS9950	BT999	NiCd	3.6 V	600 mAh		ETA272
Uniden	EXS9960	BT999	NiCd	3.6 V	600 mAh		ETA272
Uniden	EXS9965	BT999	NiCd	3.6 V	600 mAh		ETA272
Uniden	EXS9966	BT999	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXS9980	BT999	NiCd	3.6 V	600 mAh		ETA272
Uniden	EXS9995	BT999	NiCd	3.6 V	600 mAh		ETA274
Uniden	EXT1160	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXT1760	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXT1960	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXT-1960		NiCd	3.6 V	600 mAh		ETA272
Uniden	EXT1965	BT905	NiCd	3.6 V	600 mAh		ETA277

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
Uniden	EXT-1965		NiCd	3.6 V	600 mAh		ETA272
Uniden	EXTA17980	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	EXV990	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	RX16960	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU241	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU246	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU248	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU341	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU346	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU346	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU3465	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU348	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU3485	BT905	NiCd	3.6 V	600 mAh		ETA277
Uniden	TRU446	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU446-2	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU4465	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU4465-2	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU448-2	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU4485	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU4485-2	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU5856-2	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	TRU5885-2	BT446	NiMH	3.6 V	800mAh		ETA5446
Uniden	XC-265	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC-301	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC-310	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC-315	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC-320	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC-330	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC-365	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC625		NiCd	3.6 V	300 mAh		ETA248
Uniden	XC717	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XC815	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XCA1680	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XCI667	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XCIA610W	BT185	NiCd	3.6 V	300 mAh		ETA248
Uniden	XCIA680	BT185	NiCd	3.6 V	300 mAh		ETA248
Varta	VIP100/1933B		NiCd	3.6 V	600 mAh		ETA275
V-Tech	1064	1023	NiCd	3.6 V	300 mAh		ETA246
V-Tech	2600	80-5074-00-00	NiCd	3.6 V	600mAh		ETA246
V-Tech	2651	80-5074-00-00	NiCd	3.6 V	300 mAh		ETA246
V-Tech	2656	80-5074-00-00	NiCd	3.6 V	300 mAh		ETA246
V-Tech	910ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	912ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	912ADLC	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	914ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	914ADLI	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	915ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	916-ADLI		NiCd	3.6 V	600 mAh		ETA272
V-Tech	917ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	917-ADX		NiCd	3.6 V	600 mAh		ETA272
V-Tech	918ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	918-ADX	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	920ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	921-ADL	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	ADL		NiCd	3.6 V	600 mAh		ETA272
V-Tech	GZ2334	80-5074-00-00	NiCd	3.6 V	600mAh		ETA246
V-Tech	GZ2434	80-5074-00-00	NiCd	3.6 V	300 mAh		ETA246
V-Tech	GZ2456	80-5074-00-00	NiCd	3.6 V	300 mAh		ETA246
V-Tech	T2450	80-5074-00-00	NiCd	3.6 V	600mAh		ETA246
V-Tech	VSB		NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1421	80-4289-03-00	NiMH	3.6 V	600 mAh		ETA571 **
V-Tech	VT-1511	80-4289-0300	NiMH	3.6 V	600 mAh		ETA571 **
V-Tech	VT-1711	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1721	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1733	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1900	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1901	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1902	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1910	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1910c	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1911	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1920	80-4032-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1920c	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1921	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272
V-Tech	VT-1921c	80-4280-00-00	NiCd	3.6 V	600 mAh		ETA272

# ELECTROHOME

## CORDLESS PHONE BATTERY CROSS REFERENCE CHART

Phone Brand	Cordless Phone Model #	OEM Battery Model #		Chemistry	Voltage	Capacity	Electrohome Battery Model #
V-Tech	VT-1922	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-1922c	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1923	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1930	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1930c	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1932	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1940	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1951	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT1961		NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1962	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT1970	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1970c	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-1970ci	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-20-2420	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-20-2431	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-2400	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-2418	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-2420	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-2421	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-24-2481	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-2426	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-2428	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-2430	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-2431	80-5017-00-00	NiMH		2.4V	1500mAh	ETA5017
V-Tech	VT-2460	80-5017-00-00	NiMH		2.4 V	1500mAh	ETA5017
V-Tech	VT-2461	80-5017-00-00	NiMH		2.4V	1500mAh	ETA5017
V-Tech	VT-2468	80-5071-00-00	NiCd		3.6 V	600 mAh	ETA276
V-Tech	VT-2498	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-2528	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-2910	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2910C	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2910C	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2920	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2931	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2932	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2950ci	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2960	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2961	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-2962	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-5820	80-5017-00-00	NiMH		2.4V	1500mAh	ETA5017
V-Tech	VT-5831	80-5017-00-00	NiMH		2.4V	1500mAh	ETA5017
V-Tech	VT-9000	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9060	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9060I	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9105	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9108	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9109	80-5071-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9110	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9111	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9112	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9113	80-5074-00-00	NiCd		3.6 V	600 mAh	ETA246
V-Tech	VT-9115	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9116	80-5038-00-00	NiCd		3.6 V	600 mAh	ETA246
V-Tech	VT-9117	80-5038-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9118	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9119	80-5074-00-00	NiCd		3.6 V	600 mAh	ETA246
V-Tech	VT-9121	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9122	80-5038-00-00	NiCd		3.6 V	600 mAh	ETA246
V-Tech	VT-9123	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9126	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9127	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9140	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9141	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9151	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9152	80-5074-00-00	NiCd		3.6 V	600 mAh	ETA246
V-Tech	VT-9155	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9161	80-5074-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9162	80-4280-00-00	NiCd		3.6 V	300 mAh	ETA246
V-Tech	VT-9171	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-919AD	80-4032-00-00	NiCd		3.6 V	600 mAh	ETA272
V-Tech	VT-9241	80-4280-00-00	NiCd		3.6 V	600 mAh	ETA272

**\*\* These batteries are available as a special order, please see department manager for further details**