

<b>LONDON DRUGS CORDLESS PHONE BATTERY CROSS REFERENCE</b>			
<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
AT&T	1000	PP303 / HHRP303	TYPE 4
AT&T	1517	PP303 / HHRP303	TYPE 4
AT&T	1539	PP303 / HHRP303	TYPE 4
AT&T	2181	PP303 / HHRP303	TYPE 4
AT&T	200	PP501 / HHRP501	TYPE 1
AT&T	2230	PP303 / HHRP303	TYPE 4
AT&T	2255	PP303 / HHRP303	TYPE 4
AT&T	2325	PP576 / HHRP576	for GE 900MHz
AT&T	2400		NOT AVAILABLE
AT&T	2402		NOT AVAILABLE
AT&T	2414		NOT AVAILABLE
AT&T	2422	PP303 / HHRP303	TYPE 4
AT&T	2440		NOT AVAILABLE
AT&T	2455		NOT AVAILABLE
AT&T	2462		NOT AVAILABLE
AT&T	250	PP501 / HHRP501	TYPE 1
AT&T	3000	PP303 / HHRP303	TYPE 4
AT&T	3093	PP302 / HHRP302	TYPE 3
AT&T	3300		NOT AVAILABLE
AT&T	3400	PP303 / HHRP303	TYPE 4
AT&T	3410	PP303 / HHRP303	TYPE 4
AT&T	400	PP501 / HHRP501	TYPE 1
AT&T	4000 series	PP303 / HHRP303	TYPE 4
AT&T	4000A	PP303 / HHRP303	TYPE 4
AT&T	4000X	PP303 / HHRP303	TYPE 4
AT&T	4050	PP303 / HHRP303	TYPE 4
AT&T	4051	PP303 / HHRP303	TYPE 4
AT&T	4068	PP303 / HHRP303	TYPE 4
AT&T	4091	PP303 / HHRP303	TYPE 4
AT&T	4100	PP303 / HHRP303	TYPE 4
AT&T	4110	PP303 / HHRP303	TYPE 4
AT&T	4140	PP303 / HHRP303	TYPE 4
AT&T	4132	PP305 / HHRP305	TYPE 14
AT&T	4200	PP303 / HHRP303	TYPE 4
AT&T	4210	PP303 / HHRP303	TYPE 4
AT&T	4225	PP303 / HHRP303	TYPE 4
AT&T	4291	PP303 / HHRP303	TYPE 4
AT&T	4300	PP303 / HHRP303	TYPE 4
AT&T	4305	PP303 / HHRP303	TYPE 4
AT&T	4310	PP303 / HHRP303	TYPE 4
AT&T	4315	PP303 / HHRP303	TYPE 4
AT&T	4320	PP303 / HHRP303	TYPE 4
AT&T	4325	PP303 / HHRP303	TYPE 4
AT&T	4330	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
AT&T	4331	PP303 / HHRP303	TYPE 4
AT&T	4335	PP303 / HHRP303	TYPE 4
AT&T	4336	PP303 / HHRP303	TYPE 4
AT&T	4337	PP303 / HHRP303	TYPE 4
AT&T	4340	PP303 / HHRP303	TYPE 4
AT&T	4345	PP303 / HHRP303	TYPE 4
AT&T	4400	PP303 / HHRP303	TYPE 4
AT&T	4410	PP303 / HHRP303	TYPE 4
AT&T	450	PP303 / HHRP303	TYPE 4
AT&T	4500	PP303 / HHRP303	TYPE 4
AT&T	4571	PP303 / HHRP303	TYPE 4
AT&T	4600	PP303 / HHRP303	TYPE 4
AT&T	4605	PP303 / HHRP303	TYPE 4
AT&T	4610	PP303 / HHRP303	TYPE 4
AT&T	4615	PP303 / HHRP303	TYPE 4
AT&T	4690	PP303 / HHRP303	TYPE 4
AT&T	4695	PP303 / HHRP303	TYPE 4
AT&T	4725	PP303 / HHRP303	TYPE 4
AT&T	4800	PP303 / HHRP303	TYPE 4
AT&T	4805	PP303 / HHRP303	TYPE 4
AT&T	4810	PP303 / HHRP303	TYPE 4
AT&T	4815	PP303 / HHRP303	TYPE 4
AT&T	4905	PP301 / HHRP301	TYPE 2
AT&T	4935	PP301 / HHRP301	TYPE 2
AT&T	4952	PP301 / HHRP301	TYPE 2
AT&T	500	PP303 / HHRP303	TYPE 4
AT&T	5000 series	PP303 / HHRP303	TYPE 4
AT&T	5030	PP303 / HHRP303	TYPE 4
AT&T	5200	PP303 / HHRP303	TYPE 4
AT&T	5200-1	PP303 / HHRP303	TYPE 4
AT&T	5210	PP303 / HHRP303	TYPE 4
AT&T	5250	PP303 / HHRP303	TYPE 4
AT&T	5300	PP303 / HHRP303	TYPE 4
AT&T	5310	PP303 / HHRP303	TYPE 4
AT&T	5320	PP303 / HHRP303	TYPE 4
AT&T	5325	PP303 / HHRP303	TYPE 4
AT&T	5352	PP303 / HHRP303	TYPE 4
AT&T	5400	PP303 / HHRP303	TYPE 4
AT&T	5405	PP303 / HHRP303	TYPE 4
AT&T	5420	PP303 / HHRP303	TYPE 4
AT&T	5450	PP303 / HHRP303	TYPE 4
AT&T	5455	PP303 / HHRP303	TYPE 4
AT&T	5460	PP303 / HHRP303	TYPE 4
AT&T	5470	PP303 / HHRP303	TYPE 4
AT&T	5471	PP303 / HHRP303	TYPE 4
AT&T	5475	PP303 / HHRP303	TYPE 4
AT&T	5480	PP303 / HHRP303	TYPE 4
AT&T	5481	PP303 / HHRP303	TYPE 4
AT&T	5483	PP303 / HHRP303	TYPE 4
AT&T	5484	PP303 / HHRP303	TYPE 4
AT&T	5489	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
AT&T	5490	PP303 / HHRP303	TYPE 4
AT&T	5491	PP301 / HHRP301	TYPE 2
AT&T	5494r	PP303 / HHRP303	TYPE 4
AT&T	5495	PP303 / HHRP303	TYPE 4
AT&T	5495R	PP303 / HHRP303	TYPE 4
AT&T	5500	PP303 / HHRP303	TYPE 4
AT&T	5510	PP303 / HHRP303	TYPE 4
AT&T	5515	PP303 / HHRP303	TYPE 4
AT&T	5520	PP303 / HHRP303	TYPE 4
AT&T	5552	PP303 / HHRP303	TYPE 4
AT&T	5600	PP303 / HHRP303	TYPE 4
AT&T	5630	PP303 / HHRP303	TYPE 4
AT&T	5631	PP303 / HHRP303	TYPE 4
AT&T	5635	PP303 / HHRP303	TYPE 4
AT&T	5650	PP303 / HHRP303	TYPE 4
AT&T	5655	PP303 / HHRP303	TYPE 4
AT&T	5665	PP303 / HHRP303	TYPE 4
AT&T	5695	PP303 / HHRP303	TYPE 4
AT&T	5700	PP303 / HHRP303	TYPE 4
AT&T	5710	PP303 / HHRP303	TYPE 4
AT&T	5715	PP303 / HHRP303	TYPE 4
AT&T	5800		NOT AVAILABLE
AT&T	5830	PP303 / HHRP303	TYPE 4
AT&T	5840		NOT AVAILABLE
AT&T	5860	PP303 / HHRP303	TYPE 4
AT&T	59768	PP302 / HHRP302	TYPE 3
AT&T	600	PP303 / HHRP303	TYPE 4
AT&T	700	PP303 / HHRP303	TYPE 4
AT&T	7000	PP303 / HHRP303	TYPE 4
AT&T	7210	PP303 / HHRP303	TYPE 4
AT&T	7210BU	PP303 / HHRP303	TYPE 4
AT&T	7210GA	PP303 / HHRP303	TYPE 4
AT&T	7210GE	PP303 / HHRP303	TYPE 4
AT&T	7215	PP303 / HHRP303	TYPE 4
AT&T	7220	PP303 / HHRP303	TYPE 4
AT&T	7225	PP303 / HHRP303	TYPE 4
AT&T	7230	PP303 / HHRP303	TYPE 4
AT&T	7235	PP303 / HHRP303	TYPE 4
AT&T	7310	PP303 / HHRP303	TYPE 4
AT&T	7330	PP303 / HHRP303	TYPE 4
AT&T	7332	PP303 / HHRP303	TYPE 4
AT&T	7340	PP303 / HHRP303	TYPE 4
AT&T	7345	PP303 / HHRP303	TYPE 4
AT&T	740	PP303 / HHRP303	TYPE 4
AT&T	7415	PP303 / HHRP303	TYPE 4
AT&T	7420	PP303 / HHRP303	TYPE 4
AT&T	750	PP501 / HHRP501	TYPE 1
AT&T	7510	PP303 / HHRP303	TYPE 4
AT&T	7512	PP303 / HHRP303	TYPE 4
AT&T	7610	PP303 / HHRP303	TYPE 4
AT&T	7620	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
AT&T	7625	PP303 / HHRP303	TYPE 4
AT&T	7630	PP303 / HHRP303	TYPE 4
AT&T	7640	PP303 / HHRP303	TYPE 4
AT&T	7650	PP303 / HHRP303	TYPE 4
AT&T	7700	PP303 / HHRP303	TYPE 4
AT&T	7710	PP303 / HHRP303	TYPE 4
AT&T	7715	PP303 / HHRP303	TYPE 4
AT&T	7720	PP303 / HHRP303	TYPE 4
AT&T	8000	PP302 / HHRP302	TYPE 3
AT&T	8210	PP576 / HHRP576	for GE 900MHz
AT&T	8211	PP576 / HHRP576	for GE 900MHz
AT&T	8240	PP576 / HHRP576	for GE 900MHz
AT&T	8241	PP576 / HHRP576	for GE 900MHz
AT&T	8243	PP576 / HHRP576	for GE 900MHz
AT&T	8255	PP576 / HHRP576	for GE 900MHz
AT&T	8270	PP576 / HHRP576	for GE 900MHz
AT&T	9000		NOT AVAILABLE
AT&T	9002	PP900	for V-Tech 900MHz
AT&T	9050	PP900	for V-Tech 900MHz
AT&T	90848		NOT AVAILABLE
AT&T	9100	PP303 / HHRP303	TYPE 4
AT&T	9105	PP900	for V-Tech 900MHz
AT&T	9107	PP900	for V-Tech 900MHz
AT&T	9110	PP900	for V-Tech 900MHz
AT&T	9111	PP910	for V-Tech 900MHz
AT&T	9112		NOT AVAILABLE
AT&T	9115		NOT AVAILABLE
AT&T	9120	PP302 / HHRP302	TYPE 3
AT&T	9125		NOT AVAILABLE
AT&T	9130		NOT AVAILABLE
AT&T	9132	PP302 / HHRP302	TYPE 3
AT&T	9150		NOT AVAILABLE
AT&T	9200	PP900	for V-Tech 900MHz
AT&T	9210	PP576 / HHRP576	for GE 900 MHz
AT&T	9230	PP576 / HHRP576	for GE 900 MHz
AT&T	9300	PP576 / HHRP576	for GE 900 MHz
AT&T	9301	PP576 / HHRP576	for GE 900 MHz
AT&T	9307	PP576 / HHRP576	for GE 900 MHz
AT&T	9310		NOT AVAILABLE
AT&T	9311	PP576 / HHRP576	for GE 900 MHz
AT&T	9312	PP576 / HHRP576	for GE 900 MHz
AT&T	9320		NOT AVAILABLE
AT&T	9340	PP576 / HHRP576	for GE 900 MHz
AT&T	9341	PP576 / HHRP576	for GE 900 MHz
AT&T	9345		NOT AVAILABLE
AT&T	9350	PP576 / HHRP576	for GE 900 MHz
AT&T	9351	PP576 / HHRP576	for GE 900 MHz
AT&T	9353		NOT AVAILABLE
AT&T	9355	PP576 / HHRP576	for GE 900 MHz
AT&T	9357		NOT AVAILABLE
AT&T	9365	PP576 / HHRP576	for GE 900 MHz

Vendor	Phone Model #	Battery Sku	Battery Description
AT&T	9370	PP576 / HHRP576	for GE 900 MHz
AT&T	9371		NOT AVAILABLE
AT&T	9400		NOT AVAILABLE
AT&T	9401		NOT AVAILABLE
AT&T	9410	PP576 / HHRP576	for GE 900 MHz
AT&T	9450		NOT AVAILABLE
AT&T	9452	PP910	for V-Tech 900MHz
AT&T	9460	PP576 / HHRP576	for GE 900 MHz
AT&T	9465	PP576 / HHRP576	for GE 900 MHz
AT&T	9515		NOT AVAILABLE
AT&T	9555		NOT AVAILABLE
AT&T	HS-8201	PP576 / HHRP576	for GE 900 MHz
AT&T	HS-8210	PP576 / HHRP576	for GE 900 MHz
AT&T	HS-8211	PP576 / HHRP576	for GE 900 MHz
AT&T	HS-8240	PP576 / HHRP576	for GE 900 MHz
AT&T	HS-8241	PP576 / HHRP576	for GE 900 MHz
AT&T	HS-8255	PP576 / HHRP576	for GE 900 MHz
AT&T	HS-8270	PP576 / HHRP576	for GE 900 MHz
AT&T	HT-3400	PP303 / HHRP303	TYPE 4
AT&T	HT-4100	PP303 / HHRP303	TYPE 4
AT&T	HT-4110	PP303 / HHRP303	TYPE 4
AT&T	HT-4200	PP303 / HHRP303	TYPE 4
AT&T	HT-4210	PP303 / HHRP303	TYPE 4
AT&T	HT-4310	PP303 / HHRP303	TYPE 4
AT&T	HT-4320	PP303 / HHRP303	TYPE 4
AT&T	HT-4335	PP303 / HHRP303	TYPE 4
AT&T	HT-4400	PP303 / HHRP303	TYPE 4
AT&T	HT-4410	PP303 / HHRP303	TYPE 4
AT&T	HT-5200	PP303 / HHRP303	TYPE 4
AT&T	HT-5210	PP303 / HHRP303	TYPE 4
AT&T	HT-5300	PP303 / HHRP303	TYPE 4
AT&T	HT-5310	PP303 / HHRP303	TYPE 4
AT&T	HT-5320	PP303 / HHRP303	TYPE 4
AT&T	HT-5352	PP303 / HHRP303	TYPE 4
AT&T	HT-5405	PP303 / HHRP303	TYPE 4
AT&T	HT-5450	PP303 / HHRP303	TYPE 4
AT&T	HT-5470	PP303 / HHRP303	TYPE 4
AT&T	HT-5500	PP303 / HHRP303	TYPE 4
AT&T	HT-5515	PP303 / HHRP303	TYPE 4
AT&T	HT-5600	PP303 / HHRP303	TYPE 4
AT&T	HT-56001	PP303 / HHRP303	TYPE 4
AT&T	HT-6000	PP303 / HHRP303	TYPE 4
AT&T	HT-7000	PP303 / HHRP303	TYPE 4
AT&T	MLC5	PP303 / HHRP303	TYPE 4
AT&T	MERLINMLC-5	PP303 / HHRP303	TYPE 4
AT&T	AT&T Nomad 200	PP501 / HHRP501	TYPE 1
AT&T	NOMAD3000	PP303 / HHRP303	TYPE 4
AT&T	NOMAD4000	PP303 / HHRP303	TYPE 4
AT&T	NOMAD4000A	PP303 / HHRP303	TYPE 4
AT&T	NOMAD4200	PP303 / HHRP303	TYPE 4
AT&T	NOMAD4210	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
AT&T	NOMAD4400	PP303 / HHRP303	TYPE 4
AT&T	NOMAD4410	PP303 / HHRP303	TYPE 4
AT&T	NOMAD5200	PP303 / HHRP303	TYPE 4
AT&T	NOMAD5300	PP303 / HHRP303	TYPE 4
<b>BELL PHONE</b>			
BELL PHONE	32001	PP501 / HHRP501	TYPE 1
BELL PHONE	32011	PP501 / HHRP501	TYPE 1
BELL PHONE	534		NOT AVAILABLE
BELL PHONE	542		NOT AVAILABLE
BELL PHONE	582Z		NOT AVAILABLE
BELL PHONE	641		NOT AVAILABLE
BELL PHONE	660		NOT AVAILABLE
<b>BELL SOUTH</b>			
BELL SOUTH	2541		NOT AVAILABLE
BELL SOUTH	2544		NOT AVAILABLE
BELL SOUTH	2673		NOT AVAILABLE
BELL SOUTH	2676		NOT AVAILABLE
BELL SOUTH	2677		NOT AVAILABLE
BELL SOUTH	2678		NOT AVAILABLE
BELL SOUTH	2679		NOT AVAILABLE
BELL SOUTH	33009		NOT AVAILABLE
BELL SOUTH	33011		NOT AVAILABLE
BELL SOUTH	33012		NOT AVAILABLE
BELL SOUTH	33013		NOT AVAILABLE
BELL SOUTH	33014	HHRP801	TYPE 7
BELL SOUTH	33015		NOT AVAILABLE
BELL SOUTH	33016		NOT AVAILABLE
BELL SOUTH	33017		NOT AVAILABLE
BELL SOUTH	33020		NOT AVAILABLE
BELL SOUTH	3530		NOT AVAILABLE
BELL SOUTH	3531		NOT AVAILABLE
BELL SOUTH	3533		NOT AVAILABLE
BELL SOUTH	3533Z		NOT AVAILABLE
BELL SOUTH	3534		NOT AVAILABLE
BELL SOUTH	3535		NOT AVAILABLE
BELL SOUTH	3540		NOT AVAILABLE
BELL SOUTH	3541		NOT AVAILABLE
BELL SOUTH	3542		NOT AVAILABLE
BELL SOUTH	3581		NOT AVAILABLE
BELL SOUTH	3582		NOT AVAILABLE
BELL SOUTH	3583		NOT AVAILABLE
BELL SOUTH	3584		NOT AVAILABLE
BELL SOUTH	3671		NOT AVAILABLE
BELL SOUTH	3675		NOT AVAILABLE
BELL SOUTH	3685		NOT AVAILABLE
BELL SOUTH	3712		NOT AVAILABLE
BELL SOUTH	3713		NOT AVAILABLE
BELL SOUTH	3714		NOT AVAILABLE
BELL SOUTH	3722		NOT AVAILABLE
BELL SOUTH	3723		NOT AVAILABLE
BELL SOUTH	3724		NOT AVAILABLE

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
BELL SOUTH	3732		NOT AVAILABLE
BELL SOUTH	3733		NOT AVAILABLE
BELL SOUTH	3734		NOT AVAILABLE
BELL SOUTH	3866		NOT AVAILABLE
BELL SOUTH	3868		NOT AVAILABLE
BELL SOUTH	38682		NOT AVAILABLE
BELL SOUTH	3877		NOT AVAILABLE
BELL SOUTH	3887		NOT AVAILABLE
BELL SOUTH	3890		NOT AVAILABLE
BELL SOUTH	3890Z		NOT AVAILABLE
BELL SOUTH	3891		NOT AVAILABLE
BELL SOUTH	3892		NOT AVAILABLE
BELL SOUTH	3893		NOT AVAILABLE
BELL SOUTH	3894		NOT AVAILABLE
BELL SOUTH	3901	HHRP801	TYPE 7
BELL SOUTH	3903		NOT AVAILABLE
BELL SOUTH	39030		NOT AVAILABLE
BELL SOUTH	3904		NOT AVAILABLE
BELL SOUTH	3950		NOT AVAILABLE
BELL SOUTH	3951		NOT AVAILABLE
BELL SOUTH	530		NOT AVAILABLE
BELL SOUTH	5300		NOT AVAILABLE
BELL SOUTH	531		NOT AVAILABLE
BELL SOUTH	531X		NOT AVAILABLE
BELL SOUTH	532		NOT AVAILABLE
BELL SOUTH	532X		NOT AVAILABLE
BELL SOUTH	533		NOT AVAILABLE
BELL SOUTH	534		NOT AVAILABLE
BELL SOUTH	535		NOT AVAILABLE
BELL SOUTH	540		NOT AVAILABLE
BELL SOUTH	541		NOT AVAILABLE
BELL SOUTH	542		NOT AVAILABLE
BELL SOUTH	543		NOT AVAILABLE
BELL SOUTH	544		NOT AVAILABLE
BELL SOUTH	546		NOT AVAILABLE
BELL SOUTH	547		NOT AVAILABLE
BELL SOUTH	581		NOT AVAILABLE
BELL SOUTH	581B		NOT AVAILABLE
BELL SOUTH	582		NOT AVAILABLE
BELL SOUTH	582B		NOT AVAILABLE
BELL SOUTH	582Z		NOT AVAILABLE
BELL SOUTH	583		NOT AVAILABLE
BELL SOUTH	584		NOT AVAILABLE
BELL SOUTH	6000	HHRP801	TYPE 7
BELL SOUTH	624		NOT AVAILABLE
BELL SOUTH	626		NOT AVAILABLE
BELL SOUTH	627		NOT AVAILABLE
BELL SOUTH	628		NOT AVAILABLE
BELL SOUTH	629		NOT AVAILABLE
BELL SOUTH	633		NOT AVAILABLE
BELL SOUTH	634		NOT AVAILABLE

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
BELL SOUTH	636		NOT AVAILABLE
BELL SOUTH	637		NOT AVAILABLE
BELL SOUTH	638		NOT AVAILABLE
BELL SOUTH	639		NOT AVAILABLE
BELL SOUTH	640		NOT AVAILABLE
BELL SOUTH	641		NOT AVAILABLE
BELL SOUTH	660		NOT AVAILABLE
BELL SOUTH	661		NOT AVAILABLE
BELL SOUTH	664		NOT AVAILABLE
BELL SOUTH	665		NOT AVAILABLE
BELL SOUTH	666		NOT AVAILABLE
BELL SOUTH	667		NOT AVAILABLE
BELL SOUTH	668		NOT AVAILABLE
BELL SOUTH	669		NOT AVAILABLE
BELL SOUTH	670		NOT AVAILABLE
BELL SOUTH	671		NOT AVAILABLE
BELL SOUTH	672		NOT AVAILABLE
BELL SOUTH	672X		NOT AVAILABLE
BELL SOUTH	673		NOT AVAILABLE
BELL SOUTH	673BK		NOT AVAILABLE
BELL SOUTH	673X		NOT AVAILABLE
BELL SOUTH	674		NOT AVAILABLE
BELL SOUTH	674X		NOT AVAILABLE
BELL SOUTH	675		NOT AVAILABLE
BELL SOUTH	675X		NOT AVAILABLE
BELL SOUTH	676		NOT AVAILABLE
BELL SOUTH	677		NOT AVAILABLE
BELL SOUTH	678		NOT AVAILABLE
BELL SOUTH	679		NOT AVAILABLE
BELL SOUTH	680		NOT AVAILABLE
BELL SOUTH	684		NOT AVAILABLE
BELL SOUTH	685		NOT AVAILABLE
BELL SOUTH	686		NOT AVAILABLE
BELL SOUTH	6866		NOT AVAILABLE
BELL SOUTH	687		NOT AVAILABLE
BELL SOUTH	688		NOT AVAILABLE
BELL SOUTH	689		NOT AVAILABLE
BELL SOUTH	690		NOT AVAILABLE
BELL SOUTH	695		NOT AVAILABLE
BELL SOUTH	697		NOT AVAILABLE
BELL SOUTH	698		NOT AVAILABLE
BELL SOUTH	699		NOT AVAILABLE
BELL SOUTH	700		NOT AVAILABLE
BELL SOUTH	701		NOT AVAILABLE
BELL SOUTH	702		NOT AVAILABLE
BELL SOUTH	711		NOT AVAILABLE
BELL SOUTH	7110		NOT AVAILABLE
BELL SOUTH	721		NOT AVAILABLE
BELL SOUTH	756		NOT AVAILABLE
BELL SOUTH	766		NOT AVAILABLE
BELL SOUTH	769		NOT AVAILABLE

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
BELL SOUTH	788		NOT AVAILABLE
BELL SOUTH	796BK		NOT AVAILABLE
BELL SOUTH	797		NOT AVAILABLE
BELL SOUTH	798		NOT AVAILABLE
BELL SOUTH	799		NOT AVAILABLE
BELL SOUTH	810		NOT AVAILABLE
BELL SOUTH	820		NOT AVAILABLE
BELL SOUTH	822		NOT AVAILABLE
BELL SOUTH	825		NOT AVAILABLE
BELL SOUTH	826		NOT AVAILABLE
BELL SOUTH	827		NOT AVAILABLE
BELL SOUTH	837		NOT AVAILABLE
BELL SOUTH	860		NOT AVAILABLE
BELL SOUTH	861		NOT AVAILABLE
BELL SOUTH	862		NOT AVAILABLE
BELL SOUTH	863		NOT AVAILABLE
BELL SOUTH	890		NOT AVAILABLE
BELL SOUTH	890X		NOT AVAILABLE
BELL SOUTH	890Z		NOT AVAILABLE
BELL SOUTH	891		NOT AVAILABLE
BELL SOUTH	892		NOT AVAILABLE
BELL SOUTH	B650		NOT AVAILABLE
BELL SOUTH	GH9484		NOT AVAILABLE
BELL SOUTH	HAC-33015		NOT AVAILABLE
BELL SOUTH	HAC-3951		NOT AVAILABLE
BELL SOUTH	HAC5300		NOT AVAILABLE
BELL SOUTH	HAC531		NOT AVAILABLE
BELL SOUTH	HAC531XB		NOT AVAILABLE
BELL SOUTH	HAC532		NOT AVAILABLE
BELL SOUTH	HAC532X		NOT AVAILABLE
BELL SOUTH	HAC534		NOT AVAILABLE
BELL SOUTH	HAC535		NOT AVAILABLE
BELL SOUTH	HAC581		NOT AVAILABLE
BELL SOUTH	HAC581B		NOT AVAILABLE
BELL SOUTH	HAC582		NOT AVAILABLE
BELL SOUTH	HAC582B		NOT AVAILABLE
BELL SOUTH	HAC583B		NOT AVAILABLE
BELL SOUTH	HAC629		NOT AVAILABLE
BELL SOUTH	HAC639		NOT AVAILABLE
BELL SOUTH	HAC660		NOT AVAILABLE
BELL SOUTH	HAC661		NOT AVAILABLE
BELL SOUTH	HAC664		NOT AVAILABLE
BELL SOUTH	HAC665		NOT AVAILABLE
BELL SOUTH	HAC667		NOT AVAILABLE
BELL SOUTH	HAC668		NOT AVAILABLE
BELL SOUTH	HAC670X		NOT AVAILABLE
BELL SOUTH	HAC672X		NOT AVAILABLE
BELL SOUTH	HAC673X		NOT AVAILABLE
BELL SOUTH	HAC674X		NOT AVAILABLE
BELL SOUTH	HAC675		NOT AVAILABLE
BELL SOUTH	HAC677		NOT AVAILABLE

Vendor	Phone Model #	Battery Sku	Battery Description
BELL SOUTH	HAC678		NOT AVAILABLE
BELL SOUTH	HAC684		NOT AVAILABLE
BELL SOUTH	HAC688		NOT AVAILABLE
BELL SOUTH	HAC689		NOT AVAILABLE
BELL SOUTH	HAC698		NOT AVAILABLE
BELL SOUTH	HAC699		NOT AVAILABLE
BELL SOUTH	HAC700		NOT AVAILABLE
BELL SOUTH	HAC702		NOT AVAILABLE
BELL SOUTH	HAC711		NOT AVAILABLE
BELL SOUTH	HAC799		NOT AVAILABLE
BELL SOUTH	HAC810		NOT AVAILABLE
BELL SOUTH	HAC822		NOT AVAILABLE
BELL SOUTH	HAC863		NOT AVAILABLE
BELL SOUTH	HAC892		NOT AVAILABLE
BELL SOUTH	MH9003	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9005	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9006	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9007	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9017	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9018	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9019	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9020	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9022	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9033	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9040	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9043	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9045	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9050	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9060		NOT AVAILABLE
BELL SOUTH	MH9115	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9903	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9910	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9911	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9912	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9913	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9914	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9920	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9921	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9930	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9931	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9932	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9933	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9934	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	MH9950	PP575 / HHRP575	For Sanyo 900MHz
BELL SOUTH	Southwind 624		NOT AVAILABLE
BELL SOUTH	Southwind 626		NOT AVAILABLE
BELL SOUTH	Southwind 628		NOT AVAILABLE
BELL SOUTH	Southwind 636		NOT AVAILABLE
BELL SOUTH	Southwind 637		NOT AVAILABLE
BELL SOUTH	Southwind 638		NOT AVAILABLE
BELL SOUTH	Southwind 639		NOT AVAILABLE

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
BELL SOUTH	Southwind 673		NOT AVAILABLE
BELL SOUTH	Southwind 675		NOT AVAILABLE
BELL SOUTH	Southwind 676		NOT AVAILABLE
BELL SOUTH	Southwind 678		NOT AVAILABLE
BELL SOUTH	Southwind 680		NOT AVAILABLE
BELL SOUTH	Southwind 686		NOT AVAILABLE
BELL SOUTH	Southwind 697		NOT AVAILABLE
BELL SOUTH	Southwind 698		NOT AVAILABLE
BELL SOUTH	Southwind 699		NOT AVAILABLE
BELL SOUTH	Southwind 711		NOT AVAILABLE
BELL SOUTH	Southwind 7110		NOT AVAILABLE
BELL SOUTH	Southwind 721		NOT AVAILABLE
BELL SOUTH	YCL-7701		NOT AVAILABLE
BELL SOUTH	YCL-7702		NOT AVAILABLE
BELL SOUTH	YCL-7703		NOT AVAILABLE
BELL SOUTH	YCL770		NOT AVAILABLE
BELL SOUTH	YCL7701		NOT AVAILABLE
BELL SOUTH	YCL7703		NOT AVAILABLE
<b>CASIO</b>			
CASIO	2150	PP303 / HHRP303	TYPE 4
CASIO	2250	PP303 / HHRP303	TYPE 4
CASIO	2350	PP303 / HHRP303	TYPE 4
CASIO	2780	PP303 / HHRP303	TYPE 4
CASIO	2870	PP303 / HHRP303	TYPE 4
CASIO	2970	PP303 / HHRP303	TYPE 4
CASIO	CP-2575	PP576 / HHRP576	for GE 900 MHz
CASIO	CP-720	PP576 / HHRP576	for GE 900 MHz
CASIO	CP-749	PP576 / HHRP576	for GE 900 MHz
CASIO	CP-750 (HS)	PP576 / HHRP576	for GE 900 MHz
CASIO	CP-750W	PP576 / HHRP576	for GE 900 MHz
CASIO	CP-760	PP576 / HHRP576	for GE 900 MHz
CASIO	CP-820	PP576 / HHRP576	for GE 900 MHz
CASIO	CP725	PP576 / HHRP576	for GE 900 MHz
CASIO	CP760	PP576 / HHRP576	for GE 900 MHz
CASIO	CP850	PP576 / HHRP576	for GE 900 MHz
CASIO	TC-508	PP576 / HHRP576	for GE 900 MHz
CASIO	TC-530	PP576 / HHRP576	for GE 900 MHz
CASIO	TC-540	PP303 / HHRP303	TYPE 4
CASIO	TC-919	PP576 / HHRP576	for GE 900 MHz
CASIO	TC-920	PP303 / HHRP303	TYPE 4
CASIO	TC-920BK	PP576 / HHRP576	for GE 900 MHz
CASIO	TC-925	PP576 / HHRP576	for GE 900 MHz
CASIO	TC-929		NOT AVAILABLE
CASIO	TC-930 (BK)		NOT AVAILABLE
CASIO	TC-945		NOT AVAILABLE
CASIO	TC-950	PP303 / HHRP303	TYPE 4
CASIO	TC-950A	PP303 / HHRP303	TYPE 4
CASIO	TC510	PP303 / HHRP303	TYPE 4
CASIO	TC520	PP303 / HHRP303	TYPE 4
CASIO	TC535	PP303 / HHRP303	TYPE 4

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
CIDCO	CL-900	PP575 / HHRP575	For Sanyo 900MHz
CIDCO	CL906	PP575 / HHRP575	For Sanyo 900MHz
CIDCO	CL915	PP575 / HHRP575	For Sanyo 900MHz
CIDCO	CL940		NOT AVAILABLE
CIDCO	CL980		NOT AVAILABLE
CIDCO	CL990		NOT AVAILABLE
CIDCO	CL991		NOT AVAILABLE
CIDCO	CL992		NOT AVAILABLE
CIDCO	D271		NOT AVAILABLE
CIDCO	D933		NOT AVAILABLE
<b>COBRA</b>			
COBRA	213-013-9-001	PP302 / HHRP302	TYPE 3
COBRA	AN-8525	PP302 / HHRP302	TYPE 3
COBRA	AN-8526	PP302 / HHRP302	TYPE 3
COBRA	AN-8630	PP302 / HHRP302	TYPE 3
COBRA	AN-8630-25	PP302 / HHRP302	TYPE 3
COBRA	AN-8630LS	PP302 / HHRP302	TYPE 3
COBRA	CP-100	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-100S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-100SA	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-110	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-1105A	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-115	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-115A	PP501 / HHRP501	TYPE 1
COBRA	CP-115S	PP501 / HHRP501	TYPE 1
COBRA	CP-1155	PP501 / HHRP501	TYPE 1
COBRA	CP-120	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-120S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-130	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-130S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-140	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-140S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-205SA	PP501 / HHRP501	TYPE 1
COBRA	CP-2055A	PP501 / HHRP501	TYPE 1
COBRA	CP-2058A	PP501 / HHRP501	TYPE 1
COBRA	CP-210	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-210S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-220	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-220S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-2500	PP302 / HHRP302	TYPE 3
COBRA	CP-250S	PP501 / HHRP501	TYPE 1
COBRA	CP-2501	PP302 / HHRP302	TYPE 3
COBRA	CP-2505	PP302 / HHRP302	TYPE 3
COBRA	CP-2506	PP302 / HHRP302	TYPE 3
COBRA	CP-2507	PP302 / HHRP302	TYPE 3
COBRA	CP-2510	PP302 / HHRP302	TYPE 3
COBRA	CP-2525	PP302 / HHRP302	TYPE 3
COBRA	CP-2530	PP302 / HHRP302	TYPE 3
COBRA	CP-260S	PP501 / HHRP501	TYPE 1
COBRA	CP-2570	PP302 / HHRP302	TYPE 3
COBRA	CP-301S	PP575 / HHRP575	For Sanyo 900MHz

Vendor	Phone Model #	Battery Sku	Battery Description
COBRA	CP-302S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-310	PP501 / HHRP501	TYPE 1
COBRA	CP-310S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-310SA	PP501 / HHRP501	TYPE 1
COBRA	CP-320	PP501 / HHRP501	TYPE 1
COBRA	CP-320S	PP501 / HHRP501	TYPE 1
COBRA	CP-320SA	PP501 / HHRP501	TYPE 1
COBRA	CP-330	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-330S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-355	PP501 / HHRP501	TYPE 1
COBRA	CP-355S	PP501 / HHRP501	TYPE 1
COBRA	CP-43B	PP302 / HHRP302	TYPE 3
COBRA	CP-445	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-445S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-447S	PP501 / HHRP501	TYPE 1
COBRA	CP-455	PP302 / HHRP302	TYPE 3
COBRA	CP-460	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-464	PP302 / HHRP302	TYPE 3
COBRA	CP-468	PP302 / HHRP302	TYPE 3
COBRA	CP-468 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-468SA	PP302 / HHRP302	TYPE 3
COBRA	CP-468SA INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-469	PP302 / HHRP302	TYPE 3
COBRA	CP-469S	PP302 / HHRP302	TYPE 3
COBRA	CP-470	PP302 / HHRP302	TYPE 3
COBRA	CP-471	PP302 / HHRP302	TYPE 3
COBRA	CP-472	PP302 / HHRP302	TYPE 3
COBRA	CP-473	PP302 / HHRP302	TYPE 3
COBRA	CP-474	PP302 / HHRP302	TYPE 3
COBRA	CP-474S	PP302 / HHRP302	TYPE 3
COBRA	CP-475	PP302 / HHRP302	TYPE 3
COBRA	CP-475S	PP302 / HHRP302	TYPE 3
COBRA	CP-476S	PP302 / HHRP302	TYPE 3
COBRA	CP-477S	PP575 / HHRP575	For Sanyo 900MHz
COBRA	CP-480	PP302 / HHRP302	TYPE 3
COBRA	CP-481	PP302 / HHRP302	TYPE 3
COBRA	CP-482	PP302 / HHRP302	TYPE 3
COBRA	CP-482 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-483 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-484	PP302 / HHRP302	TYPE 3
COBRA	CP-484 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-484S	PP302 / HHRP302	TYPE 3
COBRA	CP-485	PP302 / HHRP302	TYPE 3
COBRA	CP-485 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-486	PP302 / HHRP302	TYPE 3
COBRA	CP-486 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-487	PP302 / HHRP302	TYPE 3
COBRA	CP-487 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-488	PP302 / HHRP302	TYPE 3
COBRA	CP-488 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-489	PP302 / HHRP302	TYPE 3

Vendor	Phone Model #	Battery Sku	Battery Description
COBRA	CP-489S	PP302 / HHRP302	TYPE 3
COBRA	CP-489 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-490	PP302 / HHRP302	TYPE 3
COBRA	CP-490 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-490-10	PP302 / HHRP302	TYPE 3
COBRA	CP-492	PP302 / HHRP302	TYPE 3
COBRA	CP-492 INTENNA	PP302 / HHRP302	TYPE 3
COBRA	CP-701	PP302 / HHRP302	TYPE 3
COBRA	CP-701 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-702	PP302 / HHRP302	TYPE 3
COBRA	CP-702 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-703	PP302 / HHRP302	TYPE 3
COBRA	CP-703 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-705	PP302 / HHRP302	TYPE 3
COBRA	CP-705 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-706	PP302 / HHRP302	TYPE 3
COBRA	CP-706 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-711	PP302 / HHRP302	TYPE 3
COBRA	CP-711 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-712	PP302 / HHRP302	TYPE 3
COBRA	CP-712 INTENNA II	PP302 / HHRP302	TYPE 3
COBRA	CP-714	PP302 / HHRP302	TYPE 3
COBRA	CP-720	PP302 / HHRP302	TYPE 3
COBRA	CP-9105	PP501 / HHRP501	TYPE 1
COBRA	CP-9125	PP501 / HHRP501	TYPE 1
COBRA	CP-9135	PP501 / HHRP501	TYPE 1
<b>CODE-A-PHONE</b>			
CODE-A-PHONE	7010	PP302 / HHRP302	TYPE 3
CODE-A-PHONE	7015	PP302 / HHRP302	TYPE 3
CODE-A-PHONE	7110	PP302 / HHRP302	TYPE 3
CODE-A-PHONE	7130	PP302 / HHRP302	TYPE 3
CODE-A-PHONE	7210	PP302 / HHRP302	TYPE 3
CODE-A-PHONE	7300		NOT AVAILABLE
<b>CONAIR</b>			
CONAIR	CTP4000	PP303 / HHRP303	TYPE 4
CONAIR	CTP6000	PP303 / HHRP303	TYPE 4
CONAIR	CTP700	PP303 / HHRP303	TYPE 4
CONAIR	CTP8000		NOT AVAILABLE
CONAIR	CTP8010		NOT AVAILABLE
CONAIR	CTP8100		NOT AVAILABLE
CONAIR	CTP8101		NOT AVAILABLE
CONAIR	CTP8110		NOT AVAILABLE
CONAIR	CTP8210	PP303 / HHRP303	TYPE 4
CONAIR	CTP8325	PP303 / HHRP303	TYPE 4
CONAIR	CTP9000	PP303 / HHRP303	TYPE 4
CONAIR	CTP9010		NOT AVAILABLE
<b>ESCORT</b>			
ESCORT	9100		NOT AVAILABLE
ESCORT	9400		NOT AVAILABLE
ESCORT	9500		NOT AVAILABLE

Vendor	Phone Model #	Battery Sku	Battery Description
GE	2-1002GE2	PP576 / HHRP576	for GE 900MHz
GE	2-1008GE2	PP576 / HHRP576	for GE 900MHz
GE	2-101	PP302 / HHRP302	TYPE 3
GE	2-1025GE2	PP576 / HHRP576	for GE 900MHz
GE	2-103	PP302 / HHRP302	TYPE 3
GE	2-1095GE2	PP576 / HHRP576	for GE 900MHz
GE	2-184	PP302 / HHRP302	TYPE 3
GE	2-189	PP302 / HHRP302	TYPE 3
GE	2-2920A	PP576 / HHRP576	for GE 900MHz
GE	2-3645	PP303 / HHRP303	TYPE 4
GE	2-5831GE3	HHRP596	for GE2.4GHz
GE	2-5838GE3	PP576 / HHRP576	for GE 900MHz
GE	2-5839GE3	PP576 / HHRP576	for GE 900MHz
GE	2-5840GE3	PP576 / HHRP576	for GE 900MHz
GE	2-5898GE6	PP576 / HHRP576	for GE 900MHz
GE	2-6700	PP303 / HHRP303	TYPE 4
GE	2-6700GE1	PP303 / HHRP303	TYPE 4
GE	2-6700ge2	PP303 / HHRP303	TYPE 4
GE	2-6730	PP303 / HHRP303	TYPE 4
GE	2-6730GE3	PP303 / HHRP303	TYPE 4
GE	2-6730HE3	PP303 / HHRP303	TYPE 4
GE	2-6790	PP303 / HHRP303	TYPE 4
GE	2-6902GE6	PP576 / HHRP576	for GE 900MHz
GE	2-6920	PP576 / HHRP576	for GE 900MHz
GE	2-6920GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6920GE1P	PP576 / HHRP576	for GE 900MHz
GE	2-6920GE2		NOT AVAILABLE
GE	2-6920Q	PP576 / HHRP576	for GE 900MHz
GE	2-6921GE2	PP576 / HHRP576	for GE 900MHz
GE	2-6925	PP576 / HHRP576	for GE 900MHz
GE	2-6928GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6928GE2	PP576 / HHRP576	for GE 900MHz
GE	2-6930		NOT AVAILABLE
GE	2-6930GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6936	PP303 / HHRP303	TYPE 4
GE	2-6936GE1	PP303 / HHRP303	TYPE 4
GE	2-6936GE1A	PP576 / HHRP576	for GE 900MHz
GE	2-6936GE2	PP576 / HHRP576	for GE 900MHz
GE	2-6938GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6938GE2	PP576 / HHRP576	for GE 900MHz
GE	2-6955GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6960GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6970GE1		NOT AVAILABLE
GE	2-6970GE2	PP303 / HHRP303	TYPE 4
GE	2-6980GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6981GE3	PP576 / HHRP576	for GE 900MHz
GE	2-6985GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6990GE1	PP576 / HHRP576	for GE 900MHz
GE	2-6990GE3	PP576 / HHRP576	for GE 900MHz
GE	2-6992GE1		NOT AVAILABLE
GE	2-6993GE1	PP576 / HHRP576	for GE 900MHz

Vendor	Phone Model #	Battery Sku	Battery Description
GE	2-6998GE1		NOT AVAILABLE
GE	2-6998GE2	PP576 / HHRP576	for GE 900MHz
GE	2-7700GE2	PP576 / HHRP576	for GE 900MHz
GE	2-7730GE2	PP576 / HHRP576	for GE 900MHz
GE	2-7910GE1	HHRP596	
GE	2-7920GE4	HHRP596	
GE	2-7928GE2	PP576 / HHRP576	for GE 900MHz
GE	2-7930	HHRP596	
GE	2-7930GE3	HHRP596	
GE	2-7931		NOT AVAILABLE
GE	2-7935GE3	HHRP596	
GE	2-7936GE1	HHRP596	
GE	2-7938GE5	PP576 / HHRP576	for GE 900MHz
GE	2-7938GE6	PP576 / HHRP576	for GE 900MHz
GE	2-7939	HHRP596	
GE	2-7939GE3	HHRP596	
GE	2-7958GE2	PP576 / HHRP576	for GE 900MHz
GE	2-7990GE3	HHRP596	
GE	2-7993		NOT AVAILABLE
GE	2-7993GE		NOT AVAILABLE
GE	2-7998GF6	PP576 / HHRP576	for GE 900MHz
GE	2-900SST		NOT AVAILABLE
GE	2-910SST		NOT AVAILABLE
GE	2-911SST		NOT AVAILABLE
GE	2-912SST		NOT AVAILABLE
GE	2-913SST		NOT AVAILABLE
GE	2-920SST		NOT AVAILABLE
GE	2-930SST		NOT AVAILABLE
GE	2-9368	PP303 / HHRP303	TYPE 4
GE	2-9414	PP302 / HHRP302	TYPE 3
GE	2-9460GE2		NOT AVAILABLE
GE	2-9500		NOT AVAILABLE
GE	2-9501		NOT AVAILABLE
GE	2-9505		NOT AVAILABLE
GE	2-9510	PP302 / HHRP302	TYPE 3
GE	2-9512	PP302 / HHRP302	TYPE 3
GE	2-9514	PP302 / HHRP302	TYPE 3
GE	2-9515	PP302 / HHRP302	TYPE 3
GE	2-9519	PP302 / HHRP302	TYPE 3
GE	2-9519A	PP302 / HHRP302	TYPE 3
GE	2-9519D	PP302 / HHRP302	TYPE 3
GE	2-9520A	PP303 / HHRP303	TYPE 4
GE	2-9522	PP302 / HHRP302	TYPE 3
GE	2-9522A	PP302 / HHRP302	TYPE 3
GE	2-9522D	PP302 / HHRP302	TYPE 3
GE	2-9525	PP302 / HHRP302	TYPE 3
GE	2-9525C	PP302 / HHRP302	TYPE 3
GE	2-9530	PP303 / HHRP303	TYPE 4
GE	2-9530A	PP303 / HHRP303	TYPE 4
GE	2-9535	PP303 / HHRP303	TYPE 4
GE	2-9535A	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
GE	2-9580	PP303 / HHRP303	TYPE 4
GE	2-9582	PP302 / HHRP302	TYPE 3
GE	2-9585		NOT AVAILABLE
GE	2-9613	PP303 / HHRP303	TYPE 4
GE	2-9614	PP303 / HHRP303	TYPE 4
GE	2-9615	PP303 / HHRP303	TYPE 4
GE	2-9616	PP303 / HHRP303	TYPE 4
GE	2-9625	PP302 / HHRP302	TYPE 3
GE	2-9625A	PP302 / HHRP302	TYPE 3
GE	2-9626	PP302 / HHRP302	TYPE 3
GE	2-9630	PP302 / HHRP302	TYPE 3
GE	2-9630A	PP302 / HHRP302	TYPE 3
GE	2-9631	PP302 / HHRP302	TYPE 3
GE	2-9631A	PP302 / HHRP302	TYPE 3
GE	2-9632	PP302 / HHRP302	TYPE 3
GE	2-9635	PP303 / HHRP303	TYPE 4
GE	2-9638	PP303 / HHRP303	TYPE 4
GE	2-9638A	PP303 / HHRP303	TYPE 4
GE	2-9640	PP303 / HHRP303	TYPE 4
GE	2-9640A	PP303 / HHRP303	TYPE 4
GE	2-9645	PP303 / HHRP303	TYPE 4
GE	2-9665	PP302 / HHRP302	TYPE 3
GE	2-9675	PP302 / HHRP302	TYPE 3
GE	2-9680	PP303 / HHRP303	TYPE 4
GE	2-9682	PP303 / HHRP303	TYPE 4
GE	2-9683	PP303 / HHRP303	TYPE 4
GE	2-9685	PP303 / HHRP303	TYPE 4
GE	2-9730	PP303 / HHRP303	TYPE 4
GE	2-9730A	PP303 / HHRP303	TYPE 4
GE	2-9735	PP303 / HHRP303	TYPE 4
GE	2-9736	PP303 / HHRP303	TYPE 4
GE	2-9738	PP303 / HHRP303	TYPE 4
GE	2-9740	PP303 / HHRP303	TYPE 4
GE	2-9745	PP303 / HHRP303	TYPE 4
GE	2-9745A	PP303 / HHRP303	TYPE 4
GE	2-9750	PP303 / HHRP303	TYPE 4
GE	2-9751	PP303 / HHRP303	TYPE 4
GE	2-9752	PP303 / HHRP303	TYPE 4
GE	2-9753	PP303 / HHRP303	TYPE 4
GE	2-9755	PP303 / HHRP303	TYPE 4
GE	2-9763	PP303 / HHRP303	TYPE 4
GE	2-9765	PP303 / HHRP303	TYPE 4
GE	2-9768	PP303 / HHRP303	TYPE 4
GE	2-9769	PP303 / HHRP303	TYPE 4
GE	2-9770	PP303 / HHRP303	TYPE 4
GE	2-9772	PP303 / HHRP303	TYPE 4
GE	2-9774	PP303 / HHRP303	TYPE 4
GE	2-9775	PP303 / HHRP303	TYPE 4
GE	2-9776	PP303 / HHRP303	TYPE 4
GE	2-9782	PP303 / HHRP303	TYPE 4
GE	2-9782A	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
GE	2-9783	PP303 / HHRP303	TYPE 4
GE	2-9783A	PP303 / HHRP303	TYPE 4
GE	2-9785	PP303 / HHRP303	TYPE 4
GE	2-9785A	PP303 / HHRP303	TYPE 4
GE	2-9790	PP303 / HHRP303	TYPE 4
GE	2-9795	PP303 / HHRP303	TYPE 4
GE	2-9821	PP302 / HHRP302	TYPE 3
GE	2-9825	PP303 / HHRP303	TYPE 4
GE	2-9910	PP576 / HHRP576	for GE 900MHz
GE	2-9910A	PP576 / HHRP576	for GE 900MHz
GE	2-9912	PP576 / HHRP576	for GE 900MHz
GE	2-9917		NOT AVAILABLE
GE	2-9918		NOT AVAILABLE
GE	2-9920	PP576 / HHRP576	for GE 900MHz
GE	2-9921	PP576 / HHRP576	for GE 900MHz
GE	2-9925	PP576 / HHRP576	for GE 900MHz
GE	2-9926	PP576 / HHRP576	for GE 900MHz
GE	2-9930	PP576 / HHRP576	for GE 900MHz
GE	2-9950	PP576 / HHRP576	for GE 900MHz
GE	2-9955	PP576 / HHRP576	for GE 900MHz
GE	2-9960		NOT AVAILABLE
GE	26920GE2-P		NOT AVAILABLE
GE	26921GE2		NOT AVAILABLE
GE	26930GE1		NOT AVAILABLE
GE	26955GE1		NOT AVAILABLE
GE	26960GE1		NOT AVAILABLE
GE	26970GE2		NOT AVAILABLE
GE	26980GE1		NOT AVAILABLE
GE	26985GE1		NOT AVAILABLE
GE	26990GE1		NOT AVAILABLE
GE	41X681	PP302 / HHRP302	TYPE 3
GE	5-2108	PP303 / HHRP303	TYPE 4
GE	5-2126	PP302 / HHRP302	TYPE 3
GE	5-2132	PP302 / HHRP302	TYPE 3
GE	5-21819A	PP302 / HHRP302	TYPE 3
GE	5-2189A	PP302 / HHRP302	TYPE 3
GE	5-2243	PP576 / HHRP576	for GE 900MHz
GE	5-2283	PP302 / HHRP302	TYPE 3
GE	5-2298D	PP302 / HHRP302	TYPE 3
GE	5-2298E	PP302 / HHRP302	TYPE 3
GE	5-2298F	PP302 / HHRP302	TYPE 3
GE	5-2300		NOT AVAILABLE
GE	5-2301	PP302 / HHRP302	TYPE 3
GE	5-2304	PP302 / HHRP302	TYPE 3
GE	5-2308	PP302 / HHRP302	TYPE 3
GE	5-2309	PP302 / HHRP302	TYPE 3
GE	5-2310	PP302 / HHRP302	TYPE 3
GE	5-2311	PP302 / HHRP302	TYPE 3
GE	5-2313	PP302 / HHRP302	TYPE 3
GE	5-2320		NOT AVAILABLE
GE	5-2342	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
GE	5-2358A	PP576 / HHRP576	for GE 900MHz
GE	5-3304	PP302 / HHRP302	TYPE 3
GE	9625GE	PP302 / HHRP302	TYPE 3
GE	TL96154	PP501 / HHRP501	TYPE 1
GE	TL96156		NOT AVAILABLE
GE	TL96158		NOT AVAILABLE
GE	TL96506		NOT AVAILABLE
GE	TL96508		NOT AVAILABLE
GE	TL96544		NOT AVAILABLE
GE/SANYO	GES-PC3F03		NOT AVAILABLE
GE/SANYO	GES-PC615		NOT AVAILABLE
GE/SANYO	GES-PC902		NOT AVAILABLE
GE/SANYO	GES-PC915		NOT AVAILABLE
GE/SANYO	GES-PCC04		NOT AVAILABLE
GE/SANYO	GES-PCF01		NOT AVAILABLE
GE/SANYO	GES-PCF02	PP501 / HHRP501	TYPE 1
GE/SANYO	GES-PCF03		NOT AVAILABLE
GE/SANYO	GES-PCF06		NOT AVAILABLE
GE/SANYO	GES-PCF09		NOT AVAILABLE
GE/SANYO	GES-PCH01	PP302 / HHRP302	TYPE 3
GE/SANYO	GES-PCH02	PP301 / HHRP301	TYPE 2
GE/SANYO	GES-PCH03	PP303 / HHRP303	TYPE 4
GE/SANYO	GES-PCH05		NOT AVAILABLE
GE/SANYO	GES-PCH06		NOT AVAILABLE
GE/SANYO	GES-PCH07	PP302 / HHRP302	TYPE 3
GE/SANYO	GES-PCL01	10018073	DISCONTINUED
GE/SANYO	GES-PCM02		NOT AVAILABLE
GOLDSTAR	2000CT	PP303 / HHRP303	TYPE 4
GOLDSTAR	200CT	PP303 / HHRP303	TYPE 4
GOLDSTAR	20X	PP303 / HHRP303	TYPE 4
GOLDSTAR	220CT	PP303 / HHRP303	TYPE 4
GOLDSTAR	500CT		NOT AVAILABLE
GOLDSTAR	CIRCA.2000	PP303 / HHRP303	TYPE 4
GTE	3150	PP302 / HHRP302	TYPE 3
HP	ALL IN ONE	10017601	
ITT	3310	PP575 / HHRP575	For Sanyo 900MHz
ITT	3320	PP575 / HHRP575	For Sanyo 900MHz
ITT	3330	PP575 / HHRP575	For Sanyo 900MHz
ITT	PC1510	PP301 / HHRP301	TYPE 2
ITT	PC1600	PP301 / HHRP301	TYPE 2
ITT	PC3310	PP575 / HHRP575	For Sanyo 900MHz
ITT	PC3320	PP575 / HHRP575	For Sanyo 900MHz
ITT	PC3330	PP575 / HHRP575	For Sanyo 900MHz
ITT	5130	PP303 / HHRP303	TYPE 4
ITT	PC590	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
JVC	TNE55	PP303 / HHRP303	TYPE 4
JVC	TN-61	PP303 / HHRP303	TYPE 4
LA PHONE	LP-418	PP303 / HHRP303	TYPE 4
LA PHONE	LP1218	PP303 / HHRP303	TYPE 4
LUCENT	3000	PP303 / HHRP303	TYPE 4
LUCENT	3400	PP303 / HHRP303	TYPE 4
LUCENT	3410	PP303 / HHRP303	TYPE 4
LUCENT	4000	PP303 / HHRP303	TYPE 4
LUCENT	4051	PP303 / HHRP303	TYPE 4
LUCENT	4110	PP303 / HHRP303	TYPE 4
LUCENT	4200	PP303 / HHRP303	TYPE 4
LUCENT	4225	PP303 / HHRP303	TYPE 4
LUCENT	4291	PP303 / HHRP303	TYPE 4
LUCENT	4300	PP303 / HHRP303	TYPE 4
LUCENT	4305	PP303 / HHRP303	TYPE 4
LUCENT	4310	PP303 / HHRP303	TYPE 4
LUCENT	4315	PP303 / HHRP303	TYPE 4
LUCENT	4320	PP303 / HHRP303	TYPE 4
LUCENT	4325	PP303 / HHRP303	TYPE 4
LUCENT	4330	PP303 / HHRP303	TYPE 4
LUCENT	4331	PP303 / HHRP303	TYPE 4
LUCENT	4335	PP303 / HHRP303	TYPE 4
LUCENT	4336	PP303 / HHRP303	TYPE 4
LUCENT	4337	PP303 / HHRP303	TYPE 4
LUCENT	4340	PP303 / HHRP303	TYPE 4
LUCENT	4345	PP303 / HHRP303	TYPE 4
LUCENT	4400	PP303 / HHRP303	TYPE 4
LUCENT	4410	PP303 / HHRP303	TYPE 4
LUCENT	4500	PP303 / HHRP303	TYPE 4
LUCENT	4571	PP303 / HHRP303	TYPE 4
LUCENT	4600	PP303 / HHRP303	TYPE 4
LUCENT	4605	PP303 / HHRP303	TYPE 4
LUCENT	4610	PP303 / HHRP303	TYPE 4
LUCENT	4615	PP303 / HHRP303	TYPE 4
LUCENT	4690	PP303 / HHRP303	TYPE 4
LUCENT	4695	PP303 / HHRP303	TYPE 4
LUCENT	4725	PP303 / HHRP303	TYPE 4
LUCENT	4800	PP303 / HHRP303	TYPE 4
LUCENT	4805	PP303 / HHRP303	TYPE 4
LUCENT	4810	PP303 / HHRP303	TYPE 4
LUCENT	4815	PP303 / HHRP303	TYPE 4
LUCENT	4905	PP301 / HHRP301	TYPE 2
LUCENT	4935	PP301 / HHRP301	TYPE 2
LUCENT	4952	PP301 / HHRP301	TYPE 2
LUCENT	500	PP303 / HHRP303	TYPE 4
LUCENT	5030	PP303 / HHRP303	TYPE 4
LUCENT	5200	PP303 / HHRP303	TYPE 4
LUCENT	5210	PP303 / HHRP303	TYPE 4
LUCENT	5250	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
LUCENT	5300	PP303 / HHRP303	TYPE 4
LUCENT	5310	PP303 / HHRP303	TYPE 4
LUCENT	5320	PP303 / HHRP303	TYPE 4
LUCENT	5352	PP303 / HHRP303	TYPE 4
LUCENT	5400	PP303 / HHRP303	TYPE 4
LUCENT	5405	PP303 / HHRP303	TYPE 4
LUCENT	5420	PP303 / HHRP303	TYPE 4
LUCENT	5450	PP303 / HHRP303	TYPE 4
LUCENT	5455	PP303 / HHRP303	TYPE 4
LUCENT	5460	PP303 / HHRP303	TYPE 4
LUCENT	5470	PP303 / HHRP303	TYPE 4
LUCENT	5471	PP303 / HHRP303	TYPE 4
LUCENT	5475	PP303 / HHRP303	TYPE 4
LUCENT	5480	PP303 / HHRP303	TYPE 4
LUCENT	5481	PP303 / HHRP303	TYPE 4
LUCENT	5483	PP303 / HHRP303	TYPE 4
LUCENT	5484	PP303 / HHRP303	TYPE 4
LUCENT	5489	PP303 / HHRP303	TYPE 4
LUCENT	5490	PP303 / HHRP303	TYPE 4
LUCENT	5491	PP301 / HHRP301	TYPE 2
LUCENT	5495	PP303 / HHRP303	TYPE 4
LUCENT	5500	PP303 / HHRP303	TYPE 4
LUCENT	5510	PP303 / HHRP303	TYPE 4
LUCENT	5515	PP303 / HHRP303	TYPE 4
LUCENT	5520	PP303 / HHRP303	TYPE 4
LUCENT	5552	PP303 / HHRP303	TYPE 4
LUCENT	5600	PP303 / HHRP303	TYPE 4
LUCENT	5630	PP303 / HHRP303	TYPE 4
LUCENT	5631	PP303 / HHRP303	TYPE 4
LUCENT	5635	PP303 / HHRP303	TYPE 4
LUCENT	5650	PP303 / HHRP303	TYPE 4
LUCENT	5655	PP303 / HHRP303	TYPE 4
LUCENT	5665	PP303 / HHRP303	TYPE 4
LUCENT	5695	PP303 / HHRP303	TYPE 4
LUCENT	5700	PP303 / HHRP303	TYPE 4
LUCENT	5710	PP303 / HHRP303	TYPE 4
LUCENT	5715	PP303 / HHRP303	TYPE 4
LUCENT	5830	PP303 / HHRP303	TYPE 4
LUCENT	5860	PP303 / HHRP303	TYPE 4
LUCENT	7	PP303 / HHRP303	TYPE 4
LUCENT	7210	PP303 / HHRP303	TYPE 4
LUCENT	7210BU	PP303 / HHRP303	TYPE 4
LUCENT	7210GA	PP303 / HHRP303	TYPE 4
LUCENT	7210GE	PP303 / HHRP303	TYPE 4
LUCENT	7215	PP303 / HHRP303	TYPE 4
LUCENT	7220	PP303 / HHRP303	TYPE 4
LUCENT	7225	PP303 / HHRP303	TYPE 4
LUCENT	7230	PP303 / HHRP303	TYPE 4
LUCENT	7235	PP303 / HHRP303	TYPE 4
LUCENT	7310	PP303 / HHRP303	TYPE 4
LUCENT	7330	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
LUCENT	7332	PP303 / HHRP303	TYPE 4
LUCENT	7340	PP303 / HHRP303	TYPE 4
LUCENT	7345	PP303 / HHRP303	TYPE 4
LUCENT	7415	PP303 / HHRP303	TYPE 4
LUCENT	7420	PP303 / HHRP303	TYPE 4
LUCENT	7510	PP303 / HHRP303	TYPE 4
LUCENT	7512	PP303 / HHRP303	TYPE 4
LUCENT	7610	PP303 / HHRP303	TYPE 4
LUCENT	7620	PP303 / HHRP303	TYPE 4
LUCENT	7630	PP303 / HHRP303	TYPE 4
LUCENT	7625	PP303 / HHRP303	TYPE 4
LUCENT	7630	PP303 / HHRP303	TYPE 4
LUCENT	7640	PP303 / HHRP303	TYPE 4
LUCENT	7650	PP303 / HHRP303	TYPE 4
LUCENT	7700	PP303 / HHRP303	TYPE 4
LUCENT	7710	PP303 / HHRP303	TYPE 4
LUCENT	7715	PP303 / HHRP303	TYPE 4
LUCENT	7720	PP303 / HHRP303	TYPE 4
LUCENT	9002	PP900	for V-Tech 900MHz
LUCENT	9050	PP900	for V-Tech 900MHz
LUCENT	9100		NOT AVAILABLE
LUCENT	9105	PP900	for V-Tech 900MHz
LUCENT	9110	PP900	for V-Tech 900MHz
LUCENT	9112		NOT AVAILABLE
LUCENT	9115		NOT AVAILABLE
LUCENT	9120		NOT AVAILABLE
LUCENT	9125		NOT AVAILABLE
LUCENT	9130		NOT AVAILABLE
LUCENT	9132		NOT AVAILABLE
LUCENT	9150		NOT AVAILABLE
LUCENT	9200	PP900	for V-Tech 900MHz
LUCENT	9300		NOT AVAILABLE
LUCENT	9310		NOT AVAILABLE
LUCENT	9340		NOT AVAILABLE
LUCENT	9350		NOT AVAILABLE
LUCENT	9410		NOT AVAILABLE
LUCENT	9460		NOT AVAILABLE
LUCENT	9465		NOT AVAILABLE
LUCENT	9515		NOT AVAILABLE
LUCENT	9555	PP303 / HHRP303	TYPE 4
LUCENT	HT-3400	PP303 / HHRP303	TYPE 4
LUCENT	HT-4200	PP303 / HHRP303	TYPE 4
LUCENT	HT-4210	PP303 / HHRP303	TYPE 4
LUCENT	HT-4400	PP303 / HHRP303	TYPE 4
LUCENT	HT-4410	PP303 / HHRP303	TYPE 4
LUCENT	HT-5200	PP303 / HHRP303	TYPE 4
LUCENT	HT-5300	PP303 / HHRP303	TYPE 4
LUCENT	HT-5320	PP303 / HHRP303	TYPE 4
LUCENT	HT-5500	PP303 / HHRP303	TYPE 4
LUCENT	HT-5600	PP303 / HHRP303	TYPE 4
LUCENT	MERLINMLC-5	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
LUCENT	NOMAD3000	PP303 / HHRP303	TYPE 4
MAGNAVOX	CDT900PC	PP303 / HHRP303	TYPE 4
MAGNAVOX	CLT252PC	PP303 / HHRP303	TYPE 4
MAGNAVOX	CLT254PC	PP303 / HHRP303	TYPE 4
MAGNAVOX	CST264PC	PP303 / HHRP303	TYPE 4
MAGNAVOX	CST266PC	PP303 / HHRP303	TYPE 4
MEMOREX	MPH6950	PP501 / HHRP501	TYPE 1
MEMOREX	MPH6996	PP501 / HHRP501	TYPE 1
MEMOREX	MPH6925		NOT AVAILABLE
MEMOREX	MPH6928B	PP501 / HHRP501	TYPE 1
MEMOREX	MPH6929	PP501 / HHRP501	TYPE 1
MEMOREX	MPH6935		NOT AVAILABLE
MEMOREX	MPH6955-05	PP501 / HHRP501	TYPE 1
MEMOREX	MPH6990	PP501 / HHRP501	TYPE 1
MEMOREX	MPH7895-04	PP501 / HHRP501	TYPE 1
MEMOREX	MPH7825		NOT AVAILABLE
MEMOREX	MPH7828		NOT AVAILABLE
MEMOREX	MPH7895	PP501 / HHRP501	TYPE 1
MEMOREX	MSP-PH2400		NOT AVAILABLE
MOTOROLA	100	HHRP801	TYPE 7
MOTOROLA	200	HHRP801	TYPE 7
MOTOROLA	2010X	HHRP801	TYPE 7
MOTOROLA	2025	HHRP801	TYPE 7
MOTOROLA	210	HHRP801	TYPE 7
MOTOROLA	2125	HHRP801	TYPE 7
MOTOROLA	2505	HHRP801	TYPE 7
MOTOROLA	3225	HHRP801	TYPE 7
MOTOROLA	3248	HHRP801	TYPE 7
MOTOROLA	3325	HHRP801	TYPE 7
MOTOROLA	3367	HHRP801	TYPE 7
MOTOROLA	350	HHRP801	TYPE 7
MOTOROLA	425	HHRP801	TYPE 7
MOTOROLA	4325	HHRP801	TYPE 7
MOTOROLA	435	HHRP801	TYPE 7
MOTOROLA	550	HHRP801	TYPE 7
MOTOROLA	5525	HHRP801	TYPE 7
MOTOROLA	55251	HHRP801	TYPE 7
MOTOROLA	555	HHRP801	TYPE 7
MOTOROLA	560	HHRP801	TYPE 7
MOTOROLA	5625	HHRP801	TYPE 7
MOTOROLA	56251	HHRP801	TYPE 7
MOTOROLA	56725	HHRP801	TYPE 7
MOTOROLA	580	HHRP801	TYPE 7
MOTOROLA	600	HHRP801	TYPE 7
MOTOROLA	610	HHRP801	TYPE 7
MOTOROLA	700	HHRP801	TYPE 7
MOTOROLA	800	HHRP801	TYPE 7
MOTOROLA	825	HHRP801	TYPE 7

Vendor	Phone Model #	Battery Sku	Battery Description
MOTOROLA	Dynasty 500	HHRP801	TYPE 7
MOTOROLA	Dynasty 550	HHRP801	TYPE 7
MOTOROLA	MA 300	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MD71	HHR3SPA2B	2 'AA' NiMH
MOTOROLA	MA350	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MA351	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MA352	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MA360	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MA361	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MA362	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MA550	PP576 / HHRP576	
MOTOROLA	MA560	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MD41	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MD451	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MD481	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MD491	PP576 / HHRP576	for GE 900MHz
MOTOROLA	MD751	PP576 / HHRP576	for GE 900MHz
MOTOROLA	VST100	HHRP801	TYPE 7
MOTOROLA	VST200	HHRP801	TYPE 7
MOTOROLA	VST2025	HHRP801	TYPE 7
MOTOROLA	VST2505	HHRP801	TYPE 7
MOTOROLA	VST3325	HHRP801	TYPE 7
MOTOROLA	VST3367	HHRP801	TYPE 7
MOTOROLA	VST350	HHRP801	TYPE 7
MOTOROLA	VST425	HHRP801	TYPE 7
MOTOROLA	VST4325	HHRP801	TYPE 7
MOTOROLA	VST435	HHRP801	TYPE 7
MOTOROLA	VST550	HHRP801	TYPE 7
MOTOROLA	VST555	HHRP801	TYPE 7
MOTOROLA	VST580	HHRP801	TYPE 7
MOTOROLA	VST600	HHRP801	TYPE 7
MOTOROLA	VST610	HHRP801	TYPE 7
MOTOROLA	VST700	HHRP801	TYPE 7
MOTOROLA	VST800	HHRP801	TYPE 7
<b>NORTHWEST BELL</b>			
NORTHWEST BELL	32112	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32113	PP303 / HHRP303	TYPE 4
NORTHWEST BELL	32505	HHRP104	TYPE 29
NORTHWEST BELL	32508	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32509-1	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32510	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32525	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32527	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32528	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32555	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32700	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	32710	PP303 / HHRP303	TYPE 4
NORTHWEST BELL	32830	PP303 / HHRP303	TYPE 4
NORTHWEST BELL	33600	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	33700	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	35110	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
NORTHWEST BELL	35500	PP303 / HHRP303	TYPE 4
NORTHWEST BELL	36100	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36170	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36240-4	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36246	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36246-M6	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36247	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36247-4	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36248	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	36248-MX	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	38200	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	38765	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39200	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39201	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39202	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39202-1	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39203	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39205	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39212	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39212-4	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39220	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39222	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39230	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39231-4	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39250	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39500	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39510	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39510-4	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39512	HHRP402	TYPE 24 / TYPE 30
NORTHWEST BELL	39520	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39522	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39525	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39526	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39601	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39605	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39610	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39610-4	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39625	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39626	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39665	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39705	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	39710	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	EXAI7960I		NOT AVAILABLE
NORTHWEST BELL	EXAi7980	PP501 / HHRP501	TYPE 1
NORTHWEST BELL	EXAI7980i	PP501 / HHRP501	TYPE 1
NORTHWEST BELL	EXAI8985	PP501 / HHRP501	TYPE 1
NORTHWEST BELL	EXAI918	PP501 / HHRP501	TYPE 1
NORTHWEST BELL	EXAI980	PP501 / HHRP501	TYPE 1
NORTHWEST BELL	39720	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	93340	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	Excursion	PP501 / HHRP501	TYPE 1

Vendor	Phone Model #	Battery Sku	Battery Description
NORTHWEST BELL	EXCURSion3000	HHRP802	TYPE 8
NORTHWEST BELL	Excursion3100	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	EXCURSion32011	PP501 / HHRP501	TYPE 1
NORTHWEST BELL	EXCURSion32101	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	Excursion32113		NOT AVAILABLE
NORTHWEST BELL	EXCURSion32505	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	EXCURSion32508	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	EXCURSion32525	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	EXCURSion32527	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	EXCURSion32750	PP302 / HHRP302	TYPE 3
NORTHWEST BELL	EXCURSion33700		NOT AVAILABLE
NORTHWEST BELL	EXCURSion38200	PP302 / HHRP302	TYPE 3
<b>PANASONIC</b>			
PANASONIC	CP320SA	PP501 / HHRP501	TYPE 1
PANASONIC	KX9768XB	PP501 / HHRP501	TYPE 1
PANASONIC	KXCC942	PP592 / HHRP592	TYPE 92
PANASONIC	KX-FMC230	PP592 / HHRP592	TYPE 92
PANASONIC	KX-P372DH	PP301 / HHRP301	TYPE 2
PANASONIC	KXFPG381	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXFPG391	HHRP104	TYPE 29
PANASONIC	KXT1410	PP501 / HHRP501	TYPE 1
PANASONIC	KXT1430	PP501 / HHRP501	TYPE 1
PANASONIC	KXT1450	PP501 / HHRP501	TYPE 1
PANASONIC	KXT1460	PP501 / HHRP501	TYPE 1
PANASONIC	KXT150W	PP301 / HHRP301	TYPE 2
PANASONIC	KXT1520	PP501 / HHRP501	TYPE 1
PANASONIC	KXT180W	PP301 / HHRP301	TYPE 2
PANASONIC	KXT187	PP301 / HHRP301	TYPE 2
PANASONIC	KXT2105	PP501 / HHRP501	TYPE 1
PANASONIC	KXT210B	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3080R	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3185DB	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3185DW	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3280	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3600	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3610	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3620	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3640	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3702	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3705	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3705R	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3710	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3712	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3720	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3725	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3730	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3732	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3748	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3800	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3805	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3805(NEW)	PP301 / HHRP301	TYPE 2

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXT3807	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3815	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3820	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3821	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3821R	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3822	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3822R	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3823	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3823R	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3824	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3825	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3831	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3832	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3835	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3838	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3842	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3845	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3848	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3850	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3855	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3857	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3860	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3870	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3875	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3880	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3880R	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3900	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3900R	PP501 / HHRP501	TYPE 1
PANASONIC	KXT3908	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3910	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3912	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3920	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3925	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3930	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3932	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3935	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3940	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3945	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3950	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3960	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3962	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3965	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3967	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3968	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3980	PP301 / HHRP301	TYPE 2
PANASONIC	KXT3990	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4065C	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4108	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4109	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4168	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4169	PP301 / HHRP301	TYPE 2

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXT4200	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4200R	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4300	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4310	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4330	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4340	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4342	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4350	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4360	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4365	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4370	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4400	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4410	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4500	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4550	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4560	PP301 / HHRP301	TYPE 2
PANASONIC	KXT4600	PP301 / HHRP301	TYPE 2
PANASONIC	KXT5712	PP301 / HHRP301	TYPE 2
PANASONIC	KXT6161	PP301 / HHRP301	TYPE 2
PANASONIC	KXT6200B	PP501 / HHRP501	TYPE 1
PANASONIC	KXT6201B	PP501 / HHRP501	TYPE 1
PANASONIC	KXT800	PP501 / HHRP501	TYPE 1
PANASONIC	KXT8832	PP501 / HHRP501	TYPE 1
PANASONIC	KXT9500	PP543	TYPE 43
PANASONIC	KXT9500C	PP543	TYPE 43
PANASONIC	KXT9505	PP543	TYPE 43
PANASONIC	KXT9509	PP543	TYPE 43
PANASONIC	KXT9520	PP543	TYPE 43
PANASONIC	KXT9550	PP543	TYPE 43
PANASONIC	KXTA38	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC100	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC100B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC100W	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1000	PP305 / HHRP305	TYPE 14
PANASONIC	KXTC1000B	PP305 / HHRP305	TYPE 14
PANASONIC	KXTC1001W	PP305 / HHRP305	TYPE 14
PANASONIC	KXTC1040W	PP305 / HHRP305	TYPE 14
PANASONIC	KXTC109	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1400	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1400B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1400W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1401B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1401W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1402	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1403	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1410	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1410B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1430	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1430W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1431W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1447PK	PP501 / HHRP501	TYPE 1

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXTC1450	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1450B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1451B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1451W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1460B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1460W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1461B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1464	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1481B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1484	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1486B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1493CB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1493CW	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC150	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1500	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1500B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1500W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1501	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1501B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1501W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1503B	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TC1520B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC155	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC157	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC160	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC162B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1628	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC165	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC170	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1700	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1700B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1701B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1701W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1703	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1703B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1710	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1710B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1711	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1711B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1711W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1713	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1720	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1720B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1721B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1722	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1723	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1731B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1733	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1733CB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1740B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1741	PP501 / HHRP501	TYPE 1

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
PANASONIC	KXTC1741B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1743	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1743B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1743W	PP501 / HHRP501	TYPE 1
PANASONIC	KXC1750B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC180	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC180B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1800	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1800B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1801B	PP510	TYPE 21
PANASONIC	KXTC1811B	PP510	TYPE 21
PANASONIC	KXTC1831B	PP510	TYPE 21
PANASONIC	KXTC185	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1850B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1851B	PP510	TYPE 21
PANASONIC	KXTC1861B	PP510	TYPE 21
PANASONIC	KXTC1866B	PP510	TYPE 21
PANASONIC	KXTC187	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC1870B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1871B	PP510	TYPE 21
PANASONIC	KXTC1881	PP510	TYPE 21
PANASONIC	KXTC1886B	PP510	TYPE 21
PANASONIC	KXTC1890B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC1891	PP510	TYPE 21
PANASONIC	KXTC1891B	PP510	TYPE 21
PANASONIC	KXTC190	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC197	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC280	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC280D	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC282	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC282B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC289	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC410	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC4109B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC415	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC4169B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC4310	PP301 / HHRP301	TYPE 2
PANASONIC	KXTC900	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC900B	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC900D	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC900W	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC901	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC901B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC901W	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC9020	HHRP40SC1B	DISCONTINUED
PANASONIC	KXTC902B	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC904	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC904B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC905	PP543	TYPE 43
PANASONIC	KXTC907	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC907B	PP501 / HHRP501	TYPE 1

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXTC909	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC910	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC910B	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC910DB	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC911	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC912	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC914	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC917HSB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC919	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC930	PP543	TYPE 43
PANASONIC	KXTC933	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC933B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC934B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC935	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC935B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC9350	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC936	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC939	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC940	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC940B	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC940W	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC942	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC955RUB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC9568XB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC956RUB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC970	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC970W	PP592 / HHRP592	TYPE 92
PANASONIC	KXTC9768XB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTC976RUB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCA50	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCC106	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCC116	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCC425	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCC440	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCC902	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCC912	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCC942	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCC942B	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCL100	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCL100B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM410	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM410W	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM412	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM412B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM415	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM417	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM418	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM420	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM422	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM424	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM425	PP301 / HHRP301	TYPE 2

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXTCM440	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM440B	PP301 / HHRP301	TYPE 2
PANASONIC	KXTCM933	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM935	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM936	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCM937	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM938	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCM939	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM939B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM940	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCM940B	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCM940D	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCM941	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM943	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM944	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM944B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM947	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM947B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTCM970	PP592 / HHRP592	TYPE 92
PANASONIC	KXTCS970	PP592 / HHRP592	TYPE 92
PANASONIC	KXTG1713	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG1713B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG1723	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG1723B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG1733	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG1733B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG200	HHRP505	TYPE 13
PANASONIC	KXTG2000ALB	PP507	DISCONTINUED
PANASONIC	KXTG2000B	PP507	DISCONTINUED
PANASONIC	KXTG200B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG200CB	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG205	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG210	HHR-P401	TYPE 16
PANASONIC	KXTG2205	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2205B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2205S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2205W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2207	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2208	HHRP513	TYPE 27
PANASONIC	KXTG2214WH	HHRP513	TYPE 27
PANASONIC	KXTG2215	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2215B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2215S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2215W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2216	HHRP513	TYPE 27
PANASONIC	KXTG2217	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2217B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2217S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2217W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2219	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2224B	HHRP513	TYPE 27

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXTG2226F	HHRP513	TYPE 27
PANASONIC	KXTG2227	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2227B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2227S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2227W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2235	HHRP513	TYPE 27
PANASONIC	KXTG2237	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2237B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2237S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2237W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2238	HHRP513	TYPE 27
PANASONIC	KXTG2239	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2247	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2247B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2247S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2247W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2248	HHRP513	TYPE 27
PANASONIC	KXTG2257	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2257B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2257S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2257W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2258	HHRP513	TYPE 27
PANASONIC	KXTG2267B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2267S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2267W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2303B	HHRP104	TYPE 29
PANASONIC	KXTG2303WH	HHRP104	TYPE 29
PANASONIC	KXTG2313F	HHRP104	TYPE 29
PANASONIC	KXTG2314B	HHRP104	TYPE 29
PANASONIC	KXTG2323	HHRP104	TYPE 29
PANASONIC	KXTG2336S	HHRP104	TYPE 29
PANASONIC	KXTG2343	HHRP104	TYPE 29
PANASONIC	KXTG2344	HHRP104	TYPE 29
PANASONIC	KXTG2346S	HHRP104	TYPE 29
PANASONIC	KXTG2352	HHRP103	TYPE 25
PANASONIC	KXTG2356S	HHRP104	TYPE 29
PANASONIC	KXTG2357	HHRP104	TYPE 29
PANASONIC	KXTG2382	HHRP103	TYPE 25
PANASONIC	KXTG2396	HHR-P401	TYPE 16
PANASONIC	KXTG2397	HHR-P401	TYPE 16
PANASONIC	KXTG240	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG2400	HHR-P401	TYPE 16
PANASONIC	KX-TG2401	PP510	TYPE 21
PANASONIC	KX-TG2403	PP510	TYPE 21
PANASONIC	KXTG2403B	PP510	TYPE 21
PANASONIC	KXTG240B	PP501 / HHRP501	TYPE 1
PANASONIC	KXTG2405	HHR-P401	TYPE 16
PANASONIC	KXTG2411	HHRP105	TYPE 31
PANASONIC	KXTG2411WH	HHRP105	TYPE 31
PANASONIC	KXTG2421	HHRP105	TYPE 31
PANASONIC	KXTG2421F	HHRP105	TYPE 31

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXTG2421P	HHRP105	TYPE 31
PANASONIC	KXTG2422	HHRP105	TYPE 31
PANASONIC	KXTG2423	HHRP105	TYPE 31
PANASONIC	KXTG2424	HHRP105	TYPE 31
PANASONIC	KXTG2424F	HHRP105	TYPE 31
PANASONIC	KXTG2431	HHRP105	TYPE 31
PANASONIC	KXTG2432	HHRP105	TYPE 31
PANASONIC	KXTG2451	PP510	TYPE 21
PANASONIC	KXTG2451B	PP510	TYPE 21
PANASONIC	KXTG2480S	HHRP104	TYPE 29
PANASONIC	KXTG2481	PP510	TYPE 21
PANASONIC	KXTG2481B	PP510	TYPE 21
PANASONIC	KXTG2481S	PP510	TYPE 21
PANASONIC	KXTG2500	HHR-P401	TYPE 16
PANASONIC	KXTG2500B	HHR-P401	TYPE 16
PANASONIC	KXTG2501	PP510	TYPE 21
PANASONIC	KXTG2503	PP510	TYPE 21
PANASONIC	KXTG2550	HHR-P401	TYPE 16
PANASONIC	KXTG2550F	HHR-P401	TYPE 16
PANASONIC	KXTG2550S	HHR-P401	TYPE 16
PANASONIC	KXTG2553	PP510	TYPE 21
PANASONIC	KXTG2553B	PP510	TYPE 21
PANASONIC	KXTG2553F	PP510	TYPE 21
PANASONIC	KXTG2553S	PP510	TYPE 21
PANASONIC	KXTG2560	HHR-P401	TYPE 16
PANASONIC	KXTG2562	PP510	TYPE 21
PANASONIC	KXTG2563	PP510	TYPE 21
PANASONIC	KXTG2563B	PP510	TYPE 21
PANASONIC	KXTG2563F	PP510	TYPE 21
PANASONIC	KXTG2563S	PP510	TYPE 21
PANASONIC	KXTG2563W	PP510	TYPE 21
PANASONIC	KXTG2564S	PP510	TYPE 21
PANASONIC	KXTG2570	HHR-P401	TYPE 16
PANASONIC	KXTG2570B	HHR-P401	TYPE 16
PANASONIC	KXTG2570S	HHR-P401	TYPE 16
PANASONIC	KXTG2575	HHR-P401	TYPE 16
PANASONIC	KXTG2583	PP510	TYPE 21
PANASONIC	KXTG2583B	PP510	TYPE 21
PANASONIC	KXTG2583S	PP510	TYPE 21
PANASONIC	KXTG2583W	PP510	TYPE 21
PANASONIC	KXTG2584	PP510	TYPE 21
PANASONIC	KXTG2584S	PP510	TYPE 21
PANASONIC	KXTG2593	PP510	TYPE 21
PANASONIC	KXTG2593B	PP510	TYPE 21
PANASONIC	KXTG2650	HHRP509	TYPE 20
PANASONIC	KXTG2650N	HHRP509	TYPE 20
PANASONIC	KXTG2670	HHRP509	TYPE 20
PANASONIC	KXTG2670N	HHRP509	TYPE 20
PANASONIC	KXTG2680	HHRP509	TYPE 20
PANASONIC	KXTG2680N	HHRP509	TYPE 20
PANASONIC	KXTG2690	HHRP509	TYPE 20

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KXTG2690N	HHRP509	TYPE 20
PANASONIC	KXTG2700	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2700S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2720S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2730B	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2730S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2730W	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2740	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2740S	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG2770	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTG4000	HHRP506	TYPE 17
PANASONIC	KXTG5050F	HHRP104	TYPE 29
PANASONIC	KXTG5050WH	HHRP104	TYPE 29
PANASONIC	KXTG5200F	HHRP104	TYPE 29
PANASONIC	KXTG5200M	HHRP104	TYPE 29
PANASONIC	KXTG5202M	HHRP104	TYPE 29
PANASONIC	KXTG5230	HHRP104	TYPE 29
PANASONIC	KXTG5240M	HHRP104	TYPE 29
PANASONIC	KXTG5421S	HHRP104	TYPE 29
PANASONIC	KXTG5422M	HHRP104	TYPE 29
PANASONIC	KXTG5428F	HHRP104	TYPE 29
PANASONIC	KXTG5428R	HHRP104	TYPE 29
PANASONIC	KXTG5431S	HHRP104	TYPE 29
PANASONIC	KXTG5432M	HHRP104	TYPE 29
PANASONIC	KXTG5438	HHRP104	TYPE 29
PANASONIC	KXTG5439	HHRP104	TYPE 29
PANASONIC	KXTG5451S	HHRP104	TYPE 29
PANASONIC	KXTG5456	HHRP104	TYPE 29
PANASONIC	KXTG5471S	HHRP104	TYPE 29
PANASONIC	KXTG5562M	HHRP104	TYPE 29
PANASONIC	KXTG5566	HHRP104	TYPE 29
PANASONIC	KXTG5571M	HHRP104	TYPE 29
PANASONIC	KXTG5576M	HHRP104	TYPE 29
PANASONIC	KXTG6500	HHRP104	TYPE 29
PANASONIC	KXTGA200B	HHRP506	TYPE 17
PANASONIC	KXTGA230	HHRP103	TYPE 25
PANASONIC	KXTGA270	HHRP402	TYPE 24 / TYPE 30
PANASONIC	KXTGA271	HHRP103	TYPE 25
PANASONIC	KXTGA272	HHRP103	TYPE 25
PANASONIC	KXTGA400	HHRP506	TYPE 17
PANASONIC	KXTGA420	HHRP506	TYPE 17
PANASONIC	KXTGA520M	HHRP104	TYPE 29
PANASONIC	KXTGA523M	HHRP104	TYPE 29
PANASONIC	KXTGA550M	HHRP104	TYPE 29
PANASONIC	KXTGA551	HHRP104	TYPE 29
PANASONIC	KXTGA552M	HHRP104	TYPE 29
PANASONIC	KXTGA650	HHRP104	TYPE 29
PANASONIC	KXTGM240B	HHRP505	TYPE 13
PANASONIC	KX-TL901B	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TS10-W	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TS17-W	PP501 / HHRP501	TYPE 1

Vendor	Phone Model #	Battery Sku	Battery Description
PANASONIC	KX-TS21-W	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TS25-W	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TS27-W	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TS400-W	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TS5-B	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TS5-W	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TSC50-B	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TSC55-B	PP501 / HHRP501	TYPE 1
PANASONIC	KX-TSC7W	PP501 / HHRP501	TYPE 1
PANASONIC	KX-VA7020	PP501 / HHRP501	TYPE 1
PANASONIC	P-01H-F2G1	PP305 / HHRP305	TYPE 14
PANASONIC	P-03RM-F2G3	PP305 / HHRP305	TYPE 14
PANASONIC	PQP-25F301A	HHRP801	TYPE 7
<b>PHILIPS</b>			
PHILIPS	CL-8050	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8100	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8150	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8160	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8170	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8180	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8190	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8202	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8230	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8232	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8240	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8241	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8245	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8305	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8310	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8320	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8340	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8400	PP910	for V-Tech 900MHz
PHILIPS	CL-8410		NOT AVAILABLE
PHILIPS	CL-8700	PP303 / HHRP303	TYPE 4
PHILIPS	CL-8740		NOT AVAILABLE
PHILIPS	CL-8750		NOT AVAILABLE
PHILIPS	CL-8900		NOT AVAILABLE
<b>PHONE MATE</b>			
PHONE MATE	2000 SERIES	PP303 / HHRP303	TYPE 4
PHONE MATE	2150	PP303 / HHRP303	TYPE 4
PHONE MATE	2250	PP303 / HHRP303	TYPE 4
PHONE MATE	2350	PP303 / HHRP303	TYPE 4
PHONE MATE	2780	PP303 / HHRP303	TYPE 4
PHONE MATE	2870	PP303 / HHRP303	TYPE 4
PHONE MATE	2970	PP303 / HHRP303	TYPE 4
PHONE MATE	CP280	PP303 / HHRP303	TYPE 4
PHONE MATE	CP725	PP303 / HHRP303	TYPE 4
PHONE MATE	CP760	PP303 / HHRP303	TYPE 4
PHONE MATE	CP820	PP303 / HHRP303	TYPE 4
PHONE MATE	CP850	PP303 / HHRP303	TYPE 4
PHONE MATE	TC508	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
PHONE MATE	TC510	PP303 / HHRP303	TYPE 4
PHONE MATE	TC520	PP303 / HHRP303	TYPE 4
PHONE MATE	TC530	PP303 / HHRP303	TYPE 4
PHONE MATE	TC535	PP303 / HHRP303	TYPE 4
PHONE MATE	TC540	PP303 / HHRP303	TYPE 4
<b>RADIO SHACK</b>			
RADIO SHACK	23-192		NOT AVAILABLE
RADIO SHACK	23-193	PP501 / HHRP501	TYPE 1
RADIO SHACK	23-195		NOT AVAILABLE
RADIO SHACK	23-196	PP302 / HHRP302	TYPE 3
RADIO SHACK	23-197	PP303 / HHRP303	TYPE 4
RADIO SHACK	23-198		DISCONTINUED
RADIO SHACK	23-280		NOT AVAILABLE
RADIO SHACK	23-281	PP301 / HHRP301	TYPE 2
RADIO SHACK	23-282		NOT AVAILABLE
RADIO SHACK	23-290		NOT AVAILABLE
RADIO SHACK	43-1001		NOT AVAILABLE
RADIO SHACK	43-1016		NOT AVAILABLE
RADIO SHACK	43-544		NOT AVAILABLE
RADIO SHACK	43-556	PP301 / HHRP301	TYPE 2
RADIO SHACK	ET-1123	PP501 / HHRP501	TYPE 1
RADIO SHACK	ET-1702	PP501 / HHRP501	TYPE 1
RADIO SHACK	ET-1703	PP501 / HHRP501	TYPE 1
RADIO SHACK	ET-3513	PP501 / HHRP501	TYPE 1
RADIO SHACK	ET-3519		NOT AVAILABLE
RADIO SHACK	ET-3529		NOT AVAILABLE
RADIO SHACK	ET-3536		NOT AVAILABLE
RADIO SHACK	ET-3537		NOT AVAILABLE
RADIO SHACK	ET-3538		NOT AVAILABLE
RADIO SHACK	ET-3815		NOT AVAILABLE
RADIO SHACK	ET-3818		NOT AVAILABLE
RADIO SHACK	ET-416		NOT AVAILABLE
RADIO SHACK	ET-496		NOT AVAILABLE
RADIO SHACK	ET-5518	PP501 / HHRP501	TYPE 1
RADIO SHACK	ET-681	PP501 / HHRP501	TYPE 1
RADIO SHACK	ET-682		NOT AVAILABLE
RADIO SHACK	ET-683	PP501 / HHRP501	TYPE 1
RADIO SHACK	ET-686	PP501 / HHRP501	TYPE 1
RADIO SHACK	TAD-725	PP501 / HHRP501	TYPE 1
RADIO SHACK	TAD-729	PP501 / HHRP501	TYPE 1
RADIO SHACK	TAD-734	PP501 / HHRP501	TYPE 1
RADIO SHACK	TAD1015	PP301 / HHRP301	TYPE 2
RADIO SHACK	TAD1016	PP301 / HHRP301	TYPE 2
<b>SAMSUNG</b>			
SAMSUNG	9100DS	PP575 / HHRP575	For Sanyo 900MHz
SAMSUNG	9100K	PP575 / HHRP575	For Sanyo 900MHz
SAMSUNG	9100SL	PP575 / HHRP575	For Sanyo 900MHz
SAMSUNG	SP-R6150		NOT AVAILABLE
SAMSUNG	SP-R6100		NOT AVAILABLE
<b>SANYO</b>			
SANYO	CAS-100	PP302 / HHRP302	TYPE 3

Vendor	Phone Model #	Battery Sku	Battery Description
SANYO	CAS-1200	PP302 / HHRP302	TYPE 3
SANYO	CAS-1200A	PP302 / HHRP302	TYPE 3
SANYO	CAS-125	PP302 / HHRP302	TYPE 3
SANYO	CAS-130	PP302 / HHRP302	TYPE 3
SANYO	CAS-150	PP302 / HHRP302	TYPE 3
SANYO	CAS-1500	PP302 / HHRP302	TYPE 3
SANYO	CAS-1500A	PP302 / HHRP302	TYPE 3
SANYO	CAS-160	PP302 / HHRP302	TYPE 3
SANYO	CAS-170	PP302 / HHRP302	TYPE 3
SANYO	CAS-837	PP302 / HHRP302	TYPE 3
SANYO	CAS-8371	PP302 / HHRP302	TYPE 3
SANYO	CAS-867	PP302 / HHRP302	TYPE 3
SANYO	CAS-887	PP302 / HHRP302	TYPE 3
SANYO	CAS-8871	PP302 / HHRP302	TYPE 3
SANYO	CAS-A900	PP302 / HHRP302	TYPE 3
SANYO	CAS1200	PP302 / HHRP302	TYPE 3
SANYO	CAS130	PP302 / HHRP302	TYPE 3
SANYO	CAS1500	PP302 / HHRP302	TYPE 3
SANYO	CAS160		NOT AVAILABLE
SANYO	CAS170	PP302 / HHRP302	TYPE 3
SANYO	CAS837	PP302 / HHRP302	TYPE 3
SANYO	CAS887	PP302 / HHRP302	TYPE 3
SANYO	CLT-156	PP302 / HHRP302	TYPE 3
SANYO	CLT-1581	PP302 / HHRP302	TYPE 3
SANYO	CLT-176	PP302 / HHRP302	TYPE 3
SANYO	CLT-177	PP302 / HHRP302	TYPE 3
SANYO	CLT-1881	PP302 / HHRP302	TYPE 3
SANYO	CLT-25	PP302 / HHRP302	TYPE 3
SANYO	CLT-30	PP302 / HHRP302	TYPE 3
SANYO	CLT-300	PP302 / HHRP302	TYPE 3
SANYO	CLT-3200	PP302 / HHRP302	TYPE 3
SANYO	CLT-33	PP302 / HHRP302	TYPE 3
SANYO	CLT-33001	PP302 / HHRP302	TYPE 3
SANYO	CLT-3300	PP302 / HHRP302	TYPE 3
SANYO	CLT-3301A	PP302 / HHRP302	TYPE 3
SANYO	CLT-36001	PP302 / HHRP302	TYPE 3
SANYO	CLT-3600	PP302 / HHRP302	TYPE 3
SANYO	CLT-4300	PP302 / HHRP302	TYPE 3
SANYO	CLT-4600	PP302 / HHRP302	TYPE 3
SANYO	CLT-520	PP302 / HHRP302	TYPE 3
SANYO	CLT-5400	PP302 / HHRP302	TYPE 3
SANYO	CLT-555	PP302 / HHRP302	TYPE 3
SANYO	CLT-556	PP302 / HHRP302	TYPE 3
SANYO	CLT-5600	PP302 / HHRP302	TYPE 3
SANYO	CLT-575	PP302 / HHRP302	TYPE 3
SANYO	CLT-576	PP302 / HHRP302	TYPE 3
SANYO	CLT-577	PP302 / HHRP302	TYPE 3
SANYO	CLT-580	PP302 / HHRP302	TYPE 3
SANYO	CLT-5881	PP302 / HHRP302	TYPE 3
SANYO	CLT-6100	PP302 / HHRP302	TYPE 3
SANYO	CLT-630	PP302 / HHRP302	TYPE 3

Vendor	Phone Model #	Battery Sku	Battery Description
SANYO	CLT-6300	PP302 / HHRP302	TYPE 3
SANYO	CLT-656	PP302 / HHRP302	TYPE 3
SANYO	CLT-657	PP302 / HHRP302	TYPE 3
SANYO	CLT-6571	PP302 / HHRP302	TYPE 3
SANYO	CLT-667	PP302 / HHRP302	TYPE 3
SANYO	CLT-670	PP302 / HHRP302	TYPE 3
SANYO	CLT-677	PP302 / HHRP302	TYPE 3
SANYO	CLT-7100	PP302 / HHRP302	TYPE 3
SANYO	CLT-7500	PP302 / HHRP302	TYPE 3
SANYO	CLT-760	PP302 / HHRP302	TYPE 3
SANYO	CLT-8201	PP302 / HHRP302	TYPE 3
SANYO	CLT-8600	PP302 / HHRP302	TYPE 3
SANYO	CLT-8601	PP302 / HHRP302	TYPE 3
SANYO	CLT-870	PP302 / HHRP302	TYPE 3
SANYO	CLT-877	PP302 / HHRP302	TYPE 3
SANYO	CLT-880	PP302 / HHRP302	TYPE 3
SANYO	CLT-8800	PP302 / HHRP302	TYPE 3
SANYO	CLT-8801	PP302 / HHRP302	TYPE 3
SANYO	CLT-908A	PP302 / HHRP302	TYPE 3
SANYO	CLT-9109	PP302 / HHRP302	TYPE 3
SANYO	CLT-917	PP302 / HHRP302	TYPE 3
SANYO	CLT-918	PP302 / HHRP302	TYPE 3
SANYO	CLT-9181	PP302 / HHRP302	TYPE 3
SANYO	CLT-920	PP302 / HHRP302	TYPE 3
SANYO	CLT-926	PP302 / HHRP302	TYPE 3
SANYO	CLT-927	PP302 / HHRP302	TYPE 3
SANYO	CLT-937	PP302 / HHRP302	TYPE 3
SANYO	CLT-947	PP302 / HHRP302	TYPE 3
SANYO	CLT-957	PP302 / HHRP302	TYPE 3
SANYO	CLT-9581	PP302 / HHRP302	TYPE 3
SANYO	CLT-966	PP302 / HHRP302	TYPE 3
SANYO	CLT-968	PP302 / HHRP302	TYPE 3
SANYO	CLT-9810	PP302 / HHRP302	TYPE 3
SANYO	CLT-9819	PP302 / HHRP302	TYPE 3
SANYO	CLT-9820	PP302 / HHRP302	TYPE 3
SANYO	CLT-9840	PP302 / HHRP302	TYPE 3
SANYO	CLT-986	PP302 / HHRP302	TYPE 3
SANYO	CLT9936G	PP576 / HHRP576	for GE 900MHz
SANYO	CLT-A900	PP302 / HHRP302	TYPE 3
SANYO	CLT-A901	PP302 / HHRP302	TYPE 3
SANYO	CLT-A902	PP302 / HHRP302	TYPE 3
SANYO	CLT-A903	PP302 / HHRP302	TYPE 3
SANYO	CLT-A905	PP302 / HHRP302	TYPE 3
<b>SHARP</b>			
SHARP	C-2651ID	PP303 / HHRP303	TYPE 4
SHARP	CL-100 (W)	PP501 / HHRP501	TYPE 1
SHARP	CL-150	PP303 / HHRP303	TYPE 4
SHARP	CL-155	PP303 / HHRP303	TYPE 4
SHARP	CL-160	PP303 / HHRP303	TYPE 4
SHARP	CL-200	PP501 / HHRP501	TYPE 1
SHARP	CL-250	PP303 / HHRP303	TYPE 4

Vendor	Phone Model #	Battery Sku	Battery Description
SHARP	CL-255	PP303 / HHRP303	TYPE 4
SHARP	CL-260	PP303 / HHRP303	TYPE 4
SHARP	CL-265ID	PP303 / HHRP303	TYPE 4
SHARP	CL-275ID	PP303 / HHRP303	TYPE 4
SHARP	CL-300	PP501 / HHRP501	TYPE 1
SHARP	CL-350	PP303 / HHRP303	TYPE 4
SHARP	CL-355	PP303 / HHRP303	TYPE 4
SHARP	CL-400	PP501 / HHRP501	TYPE 1
SHARP	CL-405	PP501 / HHRP501	TYPE 1
SHARP	CL-410	PP501 / HHRP501	TYPE 1
SHARP	CL-500	PP303 / HHRP303	TYPE 4
SHARP	CL-505	PP303 / HHRP303	TYPE 4
SHARP	CL-510	PP303 / HHRP303	TYPE 4
SHARP	CL-540	PP303 / HHRP303	TYPE 4
SHARP	CL-550	PP303 / HHRP303	TYPE 4
SHARP	CL-555	PP303 / HHRP303	TYPE 4
SHARP	CL-905		NOT AVAILABLE
SHARP	CL-980		NOT AVAILABLE
SHARP	CL-9801ID		NOT AVAILABLE
SHARP	CL-980ID		NOT AVAILABLE
SHARP	CL-981ID		NOT AVAILABLE
SHARP	CLT-902		NOT AVAILABLE
SHARP	FT-4150	PP303 / HHRP303	TYPE 4
SHARP	FT-4155	PP303 / HHRP303	TYPE 4
SHARP	FT-4160	PP303 / HHRP303	TYPE 4
SHARP	FT-4250	PP303 / HHRP303	TYPE 4
SHARP	FT-4255	PP303 / HHRP303	TYPE 4
SHARP	FT-4260	PP303 / HHRP303	TYPE 4
SHARP	FT-4265ID	PP303 / HHRP303	TYPE 4
SHARP	FT-4275ID	PP303 / HHRP303	TYPE 4
SHARP	FT-4350	PP303 / HHRP303	TYPE 4
SHARP	FT-4355	PP303 / HHRP303	TYPE 4
SHARP	FT-4400	PP501 / HHRP501	TYPE 1
SHARP	FT-5400	PP501 / HHRP501	TYPE 1
SHARP	FT-5410	PP501 / HHRP501	TYPE 1
SHARP	FT-5505	PP303 / HHRP303	TYPE 4
SHARP	FT-5510	PP303 / HHRP303	TYPE 4
SHARP	FT-5555	PP303 / HHRP303	TYPE 4
SIEMENS	AX2400	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	2400	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	2402	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	2410	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	2415	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	2420C	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	SC24020CCS	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	SC240201CCS	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	SC2410SYSG	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	SC2410SYSW	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	SC2415	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	SC2415SYSG	HHR3SPA4B	AA' (4) NiMH cells

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
SIEMENS	SC2415SYSW	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	SC242001CCS	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	4000	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	4010	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	4015	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	4200	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	4210	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	4215	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	8800	HHR3SPA4B	AA' (4) NiMH cells
SIEMENS	8825	HHR3SPA4B	AA' (4) NiMH cells
<b>SONY</b>			
SONY	BP-T16	PP301 / HHRP301	TYPE 2
SONY	BP-T18	PP501 / HHRP501	TYPE 1
SONY	BP-T26	PP302 / HHRP302	TYPE 3
SONY	BP-T27	PP303 / HHRP303	TYPE 4
SONY	BP-T31		NOT AVAILABLE
SONY	BP-T33		NOT AVAILABLE
SONY	BP-T35	PP592 / HHRP592	TYPE 92
SONY	BP-T38		NOT AVAILABLE
SONY	CL-405	PP501 / HHRP501	TYPE 1
SONY	SCT-100	HHRP40SC1B	DISCONTINUED
SONY	SPP-1000	HHRP40SC1B	DISCONTINUED
SONY	SPP-1010	HHRP40SC1B	DISCONTINUED
SONY	SPP-11H	HHRP40SC1B	DISCONTINUED
SONY	SPP-111	PP301 / HHRP301	TYPE 2
SONY	SPP-115	HHRP40SC1B	DISCONTINUED
SONY	SPP-120	HHRP40SC1B	DISCONTINUED
SONY	SPP-121	HHRP40SC1B	DISCONTINUED
SONY	SPP-130	HHRP40SC1B	DISCONTINUED
SONY	SPP-133	HHRP40SC1B	DISCONTINUED
SONY	SPP-160	HHRP40SC1B	DISCONTINUED
SONY	SPP-170	HHRP40SC1B	DISCONTINUED
SONY	SPP-180	HHRP40SC1B	DISCONTINUED
SONY	SPP-190	HHRP40SC1B	DISCONTINUED
SONY	SPP-200	HHRP40SC1B	DISCONTINUED
SONY	SPP-200C	HHRP40SC1B	DISCONTINUED
SONY	SPP-2000	HHRP40SC1B	DISCONTINUED
SONY	SPP-2010	HHRP40SC1B	DISCONTINUED
SONY	SPP-205	PP301 / HHRP301	TYPE 2
SONY	SPP-2100	HHRP40SC1B	DISCONTINUED
SONY	SPP-22H	PP303 / HHRP303	TYPE 4
SONY	SPP-250	PP301 / HHRP301	TYPE 2
SONY	SPP-3000	HHRP40SC1B	DISCONTINUED
SONY	SPP-320	HHRP40SC1B	DISCONTINUED
SONY	SPP-4000	HHRP40SC1B	DISCONTINUED
SONY	SPP-4050	HHRP40SC1B	DISCONTINUED
SONY	SPP-50	HHRP802	TYPE 8
SONY	SPP-510	HHRP802	TYPE 8
SONY	SPP-5100	HHRP40SC1B	DISCONTINUED
SONY	SPP-55	PP301 / HHRP301	TYPE 2
SONY	SPP-57	PP301 / HHRP301	TYPE 2

Vendor	Phone Model #	Battery Sku	Battery Description
SONY	SPP-58	PP301 / HHRP301	TYPE 2
SONY	SPP-60	HHRP802	TYPE 8
SONY	SPP-65	PP301 / HHRP301	TYPE 2
SONY	SPP-70	HHRP40SC1B	DISCONTINUED
SONY	SPP-71	PP301 / HHRP301	TYPE 2
SONY	SPP-72	PP301 / HHRP301	TYPE 2
SONY	SPP-72BK	PP301 / HHRP301	TYPE 2
SONY	SPP-72C	PP301 / HHRP301	TYPE 2
SONY	SPP-73	PP301 / HHRP301	TYPE 2
SONY	SPP-75	HHRP40SC1B	DISCONTINUED
SONY	SPP-77	HHRP40SC1B	DISCONTINUED
SONY	SPP-80	HHRP802	TYPE 8
SONY	SPP-85	HHRP40SC1B	DISCONTINUED
SONY	SPP-8500	HHRP40SC1B	DISCONTINUED
SONY	SPP-8700	HHRP40SC1B	DISCONTINUED
SONY	SPP-88950	PP501 / HHRP501	TYPE 1
SONY	SPP-88960	PP501 / HHRP501	TYPE 1
SONY	SPP-90	HHRP802	TYPE 8
SONY	SPP-900	PP910	For V-Tech 900MHz
SONY	SPP-900GRAY	PP501 / HHRP501	TYPE 1
SONY	SPP-901	PP900	For V-Tech 900MHz
SONY	SPP-9000	PP592 / HHRP592	TYPE 92
SONY	SPP-9001	PP592 / HHRP592	TYPE 92
SONY	SPP-9005	PP301 / HHRP301	TYPE 2
SONY	SPP-9276	PP501 / HHRP501	TYPE 1
SONY	SPP-930	PP900	For V-Tech 900MHz
SONY	SPP-930B	PP501 / HHRP501	TYPE 1
SONY	SPP-9305	PP301 / HHRP301	TYPE 2
SONY	SPP-933	PP501 / HHRP501	TYPE 1
SONY	SPP-934	PP900	For V-Tech 900MHz
SONY	SPP-935	PP900	For V-Tech 900MHz
SONY	SPP-95	HHRP40SC1B	DISCONTINUED
SONY	SPP-97	HHRP40SC1B	DISCONTINUED
SONY	SPP-A1050G	PP501 / HHRP501	TYPE 1
SONY	SPP-A1070	PP501 / HHRP501	TYPE 1
SONY	SPP-A11	PP301 / HHRP301	TYPE 2
SONY	SPP-A110	PP301 / HHRP301	TYPE 2
SONY	SPP-A115	HHRP40SC1B	DISCONTINUED
SONY	SPP-A120	HHRP40SC1B	DISCONTINUED
SONY	SPP-A160	HHRP40SC1B	DISCONTINUED
SONY	SPP-A170	HHRP40SC1B	DISCONTINUED
SONY	SPP-A180	HHRP40SC1B	DISCONTINUED
SONY	SPP-A190	HHRP40SC1B	DISCONTINUED
SONY	SPP-A20	PP301 / HHRP301	TYPE 2
SONY	SPP-A2000	HHRP40SC1B	DISCONTINUED
SONY	SPP-A2010	HHRP40SC1B	DISCONTINUED
SONY	SPP-A2100	HHRP40SC1B	DISCONTINUED
SONY	SPP-A2470		NOT AVAILABLE
SONY	SPP-A2480	PP501 / HHRP501	TYPE 1
SONY	SPP-A250	PP301 / HHRP301	TYPE 2
SONY	SPP-A260	PP301 / HHRP301	TYPE 2

Vendor	Phone Model #	Battery Sku	Battery Description
SONY	SPP-A2770		NOT AVAILABLE
SONY	SPP-A2780		NOT AVAILABLE
SONY	SPP-A320	HHRP40SC1B	DISCONTINUED
SONY	SPP-A40	PP301 / HHRP301	TYPE 2
SONY	SPP-A400	PP301 / HHRP301	TYPE 2
SONY	SPP-A420	PP301 / HHRP301	TYPE 2
SONY	SPP-A450	PP301 / HHRP301	TYPE 2
SONY	SPP-A5000	HHRP40SC1B	DISCONTINUED
SONY	SPP-A57	PP301 / HHRP301	TYPE 2
SONY	SPP-A60	PP301 / HHRP301	TYPE 2
SONY	SPP-A700	PP301 / HHRP301	TYPE 2
SONY	SPP-A700B	PP301 / HHRP301	TYPE 2
SONY	SPP-A80	PP301 / HHRP301	TYPE 2
SONY	SPP-A900	PP501 / HHRP501	TYPE 1
SONY	SPP-A9171		NOT AVAILABLE
SONY	SPP-A9276	PP501 / HHRP501	TYPE 1
SONY	SPP-A9276SILV	PP501 / HHRP501	TYPE 1
SONY	SPP-A9278	PP510	TYPE 21
SONY	SPP-A940	PP900	For V-Tech 900MHz
SONY	SPP-A940BK	PP900	For V-Tech 900MHz
SONY	SPP-A941GRY	PP900	For V-Tech 900MHz
SONY	SPP-A945	PP900	For V-Tech 900MHz
SONY	SPP-A946	PP501 / HHRP501	TYPE 1
SONY	SPP-A957	PP501 / HHRP501	TYPE 1
SONY	SPP-A967	PP501 / HHRP501	TYPE 1
SONY	SPP-A968	PP501 / HHRP501	TYPE 1
SONY	SPP-A970	PP900	For V-Tech 900MHz
SONY	SPP-A97	HHRP40SC1B	DISCONTINUED
SONY	SPP-A972	PP900	For V-Tech 900MHz
SONY	SPP-A972GRA	PP501 / HHRP501	TYPE 1
SONY	SPP-A973	PP900	For V-Tech 900MHz
SONY	SPP-A975	PP900	For V-Tech 900MHz
SONY	SPP-A985	PP900	For V-Tech 900MHz
SONY	SPP-AQ120	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ150	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ25	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ300	HHRP40SC1B	DISCONTINUED
SONY	SPP-AQ400	HHRP40SC1B	DISCONTINUED
SONY	SPP-AQ50	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ500	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ55	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ57	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ60	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ600	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ65	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ700	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ71	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ72C	PP301 / HHRP301	TYPE 2
SONY	SPP-AQ73	PP301 / HHRP301	TYPE 2
SONY	SPP-D900	PP501 / HHRP501	TYPE 1
SONY	SPP-ER1	PP501 / HHRP501	TYPE 1

Vendor	Phone Model #	Battery Sku	Battery Description
SONY	SPP-ER101	PP501 / HHRP501	TYPE 1
SONY	SPP-FX77	HHRP40SC1B	DISCONTINUED
SONY	SPP-FX88	HHRP40SC1B	DISCONTINUED
SONY	SPP-FX880	HHRP40SC1B	DISCONTINUED
SONY	SPP-FX882	HHRP40SC1B	DISCONTINUED
SONY	SPP-H273		NOT AVAILABLE
SONY	SPP-H278		NOT AVAILABLE
SONY	SPP-ID200	HHRP40SC1B	DISCONTINUED
SONY	SPP-ID2000	HHRP40SC1B	DISCONTINUED
SONY	SPP-ID300	PP301 / HHRP301	TYPE 2
SONY	SPP-ID300C	PP301 / HHRP301	TYPE 2
SONY	SPP-ID400	PP301 / HHRP301	TYPE 2
SONY	SPP-ID910	PP900	For V-Tech 900MHz
SONY	SPP-ID920	PP900	For V-Tech 900MHz
SONY	SPP-ID930	PP900	For V-Tech 900MHz
SONY	SPP-ID940	PP900	For V-Tech 900MHz
SONY	SPP-ID970	PP900	For V-Tech 900MHz
SONY	SPP-1D971	PP900	For V-Tech 900MHz
SONY	SPP-ID975	PP900	For V-Tech 900MHz
SONY	SPP-IM977	PP900	For V-Tech 900MHz
SONY	SPP-IM982	PP900	For V-Tech 900MHz
SONY	SPP-J32	HHRP40SC1B	DISCONTINUED
SONY	SPP-L100	HHRP40SC1B	DISCONTINUED
SONY	SPP-L33	HHRP40SC1B	DISCONTINUED
SONY	SPP-L33H	HHRP40SC1B	DISCONTINUED
SONY	SPP-L333	HHRP40SC1B	DISCONTINUED
SONY	SPP-L338	HHRP40SC1B	DISCONTINUED
SONY	SPP-LX55	HHRP40SC1B	DISCONTINUED
SONY	SPP-LX550	HHRP40SC1B	DISCONTINUED
SONY	SPP-M100	HHRP40SC1B	DISCONTINUED
SONY	SPP-M502	PP301 / HHRP301	TYPE 2
SONY	SPP-M920	PP900	For V-Tech 900MHz
SONY	SPP-M932	PP900	For V-Tech 900MHz
SONY	SPP-M937	PP900	For V-Tech 900MHz
SONY	SPP-N1020	PP501 / HHRP501	TYPE 1
SONY	SPP-N1025	PP501 / HHRP501	TYPE 1
SONY	SPP-N1025G	PP501 / HHRP501	TYPE 1
SONY	SPP-Q100	HHRP40SC1B	DISCONTINUED
SONY	SPP-Q105	HHRP40SC1B	DISCONTINUED
SONY	SPP-Q110	PP301 / HHRP301	TYPE 2
SONY	SPP-Q120	PP301 / HHRP301	TYPE 2
SONY	SPP-Q150	PP301 / HHRP301	TYPE 2
SONY	SPP-Q200	HHRP40SC1B	DISCONTINUED
SONY	SPP-Q200CR	HHRP40SC1B	DISCONTINUED
SONY	SPP-Q210	HHRP40SC1B	DISCONTINUED
SONY	SPP-Q300	HHRP40SC1B	DISCONTINUED
SONY	SPP-Q400	HHRP40SC1B	DISCONTINUED
SONY	SPP-Q405	HHRP40SC1B	DISCONTINUED
SONY	SPP-QA500	PP501 / HHRP501	TYPE 1
SONY	SPP-QAQ600	PP303 / HHRP303	TYPE 4
SONY	SPP-S10	HHRP40SC1B	DISCONTINUED

Vendor	Phone Model #	Battery Sku	Battery Description
SONY	SPP-S100	HHRP40SC1B	DISCONTINUED
SONY	SPP-S20	HHRP40SC1B	DISCONTINUED
SONY	SPP-S2430	PP501 / HHRP501	TYPE 1
SONY	SPP-S2720		NOT AVAILABLE
SONY	SPP-S2730		NOT AVAILABLE
SONY	SPP-S9000		NOT AVAILABLE
SONY	SPP-S9001		NOT AVAILABLE
SONY	SPP-S9101		NOT AVAILABLE
SONY	SPP-S9226	PP501 / HHRP501	TYPE 1
SONY	SPP-SS950	PP501 / HHRP501	TYPE 1
SONY	SPP-SS951GRY	PP501 / HHRP501	TYPE 1
SONY	SPP-SS955	PP501 / HHRP501	TYPE 1
SONY	SPP-SS960	PP501 / HHRP501	TYPE 1
SONY	SPP-SS961	PP501 / HHRP501	TYPE 1
SONY	SPP-SS965	PP501 / HHRP501	TYPE 1
SONY	SPP-SS966-S	PP501 / HHRP501	TYPE 1
SONY	SPP-SS967	PP501 / HHRP501	TYPE 1
SONY	SPP-V72C	PP301 / HHRP301	TYPE 2
SONY	SPP-V73	PP301 / HHRP301	TYPE 2
SONY	SPP-X30	HHRP40SC1B	DISCONTINUED
SONY	SPP-X50	HHRP40SC1B	DISCONTINUED
SONY	SPP-X700	HHRP40SC1B	DISCONTINUED
SONY	SPP-X90	HHRP40SC1B	DISCONTINUED
SONY	ST-250	PP301 / HHRP301	TYPE 2
<b>SOUTHWESTERN BELL</b>			
SOUTHWESTERN BELL	FF-1150	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-1175	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-1185	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-1188	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-1700	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-1710	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-1722	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-1725		NOT AVAILABLE
SOUTHWESTERN BELL	FF-1755	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-1762	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-1765	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-1775	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-4500	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-5000	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-641	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-642	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-643	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-646	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-650	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-655	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-660	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-665	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-667	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-670	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-672	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-674	PP302 / HHRP302	TYPE 3

Vendor	Phone Model #	Battery Sku	Battery Description
SOUTHWESTERN BELL	FF-675	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-676	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-677	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-685	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-690	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-692	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-693	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-694	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-694B	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-695	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-700	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-701	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-705	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-714	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-720	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-901	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	FF-905	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	FF-908	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	S60503	PP302 / HHRP302	TYPE 3
SOUTHWESTERN BELL	S60505	PP501 / HHRP501	TYPE 1
SOUTHWESTERN BELL	S60506	PP303 / HHRP303	TYPE 4
SOUTHWESTERN BELL	S60508	PP301 / HHRP301	TYPE 2
SOUTHWESTERN BELL	S60510	HHRP40SC1B	DISCONTINUED
SOUTHWESTERN BELL	S60526		NOT AVAILABLE
SOUTHWESTERN BELL	SST960		NOT AVAILABLE
<b>TELEMED</b>			
TELEMED	TEL5000	PP301 / HHRP301	TYPE 2
TELEMED	TEL5050	PP301 / HHRP301	TYPE 2
TELEMED	TEL6000	PP301 / HHRP301	TYPE 2
TELEMED	TEL6050	PP301 / HHRP301	TYPE 2
TELEMED	TEL7000	PP301 / HHRP301	TYPE 2
<b>TOSHIBA</b>			
TOSHIBA	FT-1000	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-1500	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-200	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-2000	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-2500	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-3005	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-3806	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-3808	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-3808BK	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-6000	HHRP802	TYPE 8
TOSHIBA	FT-6002	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6003	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6004	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6014	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6100	HHRP802	TYPE 8
TOSHIBA	FT-6102	HHRP802	TYPE 8
TOSHIBA	FT-6200	HHRP802	TYPE 8
TOSHIBA	FT-6202	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6203	PP301 / HHRP301	TYPE 2

Vendor	Phone Model #	Battery Sku	Battery Description
TOSHIBA	FT-6210	HHRP802	TYPE 8
TOSHIBA	FT-6300	HHRP802	TYPE 8
TOSHIBA	FT-6302	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6303	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6305	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6310	HHRP802	TYPE 8
TOSHIBA	FT-6400	HHRP802	TYPE 8
TOSHIBA	FT-6503	PP302 / HHRP302	TYPE 3
TOSHIBA	FT-6505	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6515	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6603	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-6604	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7006	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7106	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7116	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7257	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7305	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7505	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7515	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7517	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7807	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-7907	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-8006	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-8006A	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-8258		NOT AVAILABLE
TOSHIBA	FT-8259	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-8259BK	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-8507	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-8508		NOT AVAILABLE
TOSHIBA	FT-8808		NOT AVAILABLE
TOSHIBA	FT-8900	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-8906	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-8906A	PP501 / HHRP501	TYPE 1
TOSHIBA	FT-8908		NOT AVAILABLE
TOSHIBA	FT-8958		NOT AVAILABLE
TOSHIBA	FT-9003	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-9005	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-9006	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-9066	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-9305	PP301 / HHRP301	TYPE 2
TOSHIBA	FT-9506	PP301 / HHRP301	TYPE 2
TOSHIBA	FTH-8906	PP501 / HHRP501	TYPE 1
TOSHIBA	FTH-916BK	PP501 / HHRP501	TYPE 1
TOSHIBA	FTH-986BK	PP501 / HHRP501	TYPE 1
TOSHIBA	FTX-988	PP501 / HHRP501	TYPE 1
TOSHIBA	SG-1000		NOT AVAILABLE
TOSHIBA	SG-1700	PP501 / HHRP501	TYPE 1
TOSHIBA	SG-1801	PP501 / HHRP501	TYPE 1
TOSHIBA	SG-1981	PP501 / HHRP501	TYPE 1
TOSHIBA	SX-2007	PP501 / HHRP501	TYPE 1
TOSHIBA	SX-2007BK	PP501 / HHRP501	TYPE 1

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
TOSHIBA	SX-2009	PP501 / HHRP501	TYPE 1
TOSHIBA	SX-2258		NOT AVAILABLE
TOSHIBA	SX-2258BK		NOT AVAILABLE
TOSHIBA	SX-2808		NOT AVAILABLE
TOSHIBA	SX-2809	PP501 / HHRP501	TYPE 1
TOSHIBA	SX-2908		NOT AVAILABLE
TOSHIBA	SX-2908BK		NOT AVAILABLE
TOSHIBA	SX-2930	PP501 / HHRP501	TYPE 1
TOSHIBA	TRB 8258		NOT AVAILABLE
TOSHIBA	TRB6500	PP301 / HHRP301	TYPE 2
TOSHIBA	TRB8000	PP501 / HHRP501	TYPE 1
TOSHIBA	TRB9100	PP501 / HHRP501	TYPE 1
<b>UNIDEN</b>	<b>7080</b>	<b>PP302 / HHRP302</b>	<b>TYPE 3</b>
UNIDEN	AE155	HHRP801	TYPE 7
UNIDEN	AE156	HHRP801	TYPE 7
UNIDEN	AE255	PP501 / HHRP501	TYPE 1
UNIDEN	AE-355	HHRP802	TYPE 8
UNIDEN	AI7950EX	PP501 / HHRP501	TYPE 1
UNIDEN	AM-468V	PP301 / HHRP301	TYPE 2
UNIDEN	B1000	PP501 / HHRP501	TYPE 1
UNIDEN	B300	PP501 / HHRP501	TYPE 1
UNIDEN	B300A	PP501 / HHRP501	TYPE 1
UNIDEN	B3801	PP501 / HHRP501	TYPE 1
UNIDEN	B3810	PP501 / HHRP501	TYPE 1
UNIDEN	B4101	PP501 / HHRP501	TYPE 1
UNIDEN	B900	PP501 / HHRP501	TYPE 1
UNIDEN	BA300	PP501 / HHRP501	TYPE 1
UNIDEN	BA300A	PP501 / HHRP501	TYPE 1
UNIDEN	BBTY-0251001	HHRP40SC1B	DISCONTINUED
UNIDEN	BBTY-0275001	PP301 / HHRP301	TYPE 2
UNIDEN	BBTY-030001	PP501 / HHRP501	TYPE 1
UNIDEN	BBTY0324001	PP305 / HHRP305	TYPE 14
UNIDEN	BBTY-0405001	PP900	For V-Tech 900MHz
UNIDEN	BP2499		NOT AVAILABLE
UNIDEN	BP800	PP501 / HHRP501	TYPE 1
UNIDEN	BP904	PP501 / HHRP501	TYPE 1
UNIDEN	BP905	PP501 / HHRP501	TYPE 1
UNIDEN	BP910		NOT AVAILABLE
UNIDEN	BP9100		NOT AVAILABLE
UNIDEN	BP9200		NOT AVAILABLE
UNIDEN	BP990		NOT AVAILABLE
UNIDEN	BP999	PP900	For V-Tech 900MHz
UNIDEN	BP-T40	HHRP40SC1B	DISCONTINUED
UNIDEN	BT-098		NOT AVAILABLE
UNIDEN	BT-185	PP301 / HHRP301	TYPE 2
UNIDEN	BT-446		NOT AVAILABLE
UNIDEN	BT-800	PP501 / HHRP501	TYPE 1
UNIDEN	BT-801	PP305 / HHRP305	TYPE 14
UNIDEN	BT-9000	HHRP40SC1B	DISCONTINUED
UNIDEN	BT-901		NOT AVAILABLE

Vendor	Phone Model #	Battery Sku	Battery Description
UNIDEN	BT-904		NOT AVAILABLE
UNIDEN	BT-905	PP501 / HHRP501	TYPE 1
UNIDEN	BT-9100		NOT AVAILABLE
UNIDEN	BT-9200		NOT AVAILABLE
UNIDEN	BT-990		NOT AVAILABLE
UNIDEN	BT-999	PP501 / HHRP501	TYPE 1
UNIDEN	CP-355	PP501 / HHRP501	TYPE 1
UNIDEN	CT-301	PP301 / HHRP301	TYPE 2
UNIDEN	CT-350	HHRP801	TYPE 7
UNIDEN	CT-355	HHRP802	TYPE 8
UNIDEN	CT-575	HHRP802	TYPE 8
UNIDEN	CT-785S	HHRP802	TYPE 8
UNIDEN	DX-34	PP301 / HHRP301	TYPE 2
UNIDEN	DX355	PP301 / HHRP301	TYPE 2
UNIDEN	DX3555	PP301 / HHRP301	TYPE 2
UNIDEN	DX3565	PP301 / HHRP301	TYPE 2
UNIDEN	DX419	PP301 / HHRP301	TYPE 2
UNIDEN	DX434	PP301 / HHRP301	TYPE 2
UNIDEN	DX4519	PP301 / HHRP301	TYPE 2
UNIDEN	DX4534	PP301 / HHRP301	TYPE 2
UNIDEN	DX634	PP301 / HHRP301	TYPE 2
UNIDEN	DX719	PP301 / HHRP301	TYPE 2
UNIDEN	DX734	PP301 / HHRP301	TYPE 2
UNIDEN	DX8200	PP301 / HHRP301	TYPE 2
UNIDEN	DX834	PP301 / HHRP301	TYPE 2
UNIDEN	DX-85	PP301 / HHRP301	TYPE 2
UNIDEN	DXA6505	PP301 / HHRP301	TYPE 2
UNIDEN	DXA6506	PP301 / HHRP301	TYPE 2
UNIDEN	DXAI5188-2A	PP501 / HHRP501	TYPE 1
UNIDEN	DXAI5588-2A	PP501 / HHRP501	TYPE 1
UNIDEN	DXAI685	PP301 / HHRP301	TYPE 2
UNIDEN	DXI386-2	PP501 / HHRP501	TYPE 1
UNIDEN	DXI4286-2CA	PP501 / HHRP501	TYPE 1
UNIDEN	DXI5186-2A	PP501 / HHRP501	TYPE 1
UNIDEN	DXI5586-2A	PP501 / HHRP501	TYPE 1
UNIDEN	DXI665	PP301 / HHRP301	TYPE 2
UNIDEN	DXI665S	PP301 / HHRP301	TYPE 2
UNIDEN	DXI860	PP301 / HHRP301	TYPE 2
UNIDEN	DXI860C	PP301 / HHRP301	TYPE 2
UNIDEN	DXI986-2CA	PP501 / HHRP501	TYPE 1
UNIDEN	EHD1200	PP501 / HHRP501	TYPE 1
UNIDEN	EHD1200GB	PP501 / HHRP501	TYPE 1
UNIDEN	EP200	PP501 / HHRP501	TYPE 1
UNIDEN	EX1000	PP501 / HHRP501	TYPE 1
UNIDEN	EX1100		NOT AVAILABLE
UNIDEN	EX1150		NOT AVAILABLE
UNIDEN	EX155	HHRP801	TYPE 7
UNIDEN	EX-16960	PP501 / HHRP501	TYPE 1
UNIDEN	EX-17926	PP501 / HHRP501	TYPE 1
UNIDEN	EX-17960	PP501 / HHRP501	TYPE 1
UNIDEN	EX-18600A	PP501 / HHRP501	TYPE 1

Vendor	Phone Model #	Battery Sku	Battery Description
UNIDEN	EX-18965A	PP501 / HHRP501	TYPE 1
UNIDEN	EX1916	PP501 / HHRP501	TYPE 1
UNIDEN	EX1917	PP501 / HHRP501	TYPE 1
UNIDEN	EX1960	PP501 / HHRP501	TYPE 1
UNIDEN	EX1975	PP501 / HHRP501	TYPE 1
UNIDEN	EX1980	PP501 / HHRP501	TYPE 1
UNIDEN	EX19S	PP501 / HHRP501	TYPE 1
UNIDEN	EX200	PP301 / HHRP301	TYPE 2
UNIDEN	EX2000		NOT AVAILABLE
UNIDEN	EX2100	PP501 / HHRP501	TYPE 1
UNIDEN	EX2101		NOT AVAILABLE
UNIDEN	EX250	HHRP802	TYPE 8
UNIDEN	EX255	PP501 / HHRP501	TYPE 1
UNIDEN	EX2600	PP301 / HHRP301	TYPE 2
UNIDEN	EX2700	PP301 / HHRP301	TYPE 2
UNIDEN	EX300	PP501 / HHRP501	TYPE 1
UNIDEN	EX3000	PP575 / HHRP575	For Sanyo 900MHz
UNIDEN	EX3100	PP575 / HHRP575	For Sanyo 900MHz
UNIDEN	EX3101	PP501 / HHRP501	TYPE 1
UNIDEN	EX3102	PP501 / HHRP501	TYPE 1
UNIDEN	EX3182	PP575 / HHRP575	For Sanyo 900MHz
UNIDEN	EX3200		NOT AVAILABLE
UNIDEN	EX3201		NOT AVAILABLE
UNIDEN	EX3300	PP501 / HHRP501	TYPE 1
UNIDEN	EX3500		NOT AVAILABLE
UNIDEN	EX355		NOT AVAILABLE
UNIDEN	EX3600		NOT AVAILABLE
UNIDEN	EX3610		NOT AVAILABLE
UNIDEN	EX3800	PP501 / HHRP501	TYPE 1
UNIDEN	EX3810	PP501 / HHRP501	TYPE 1
UNIDEN	EX400	HHRP801	TYPE 7
UNIDEN	EX4000	PP501 / HHRP501	TYPE 1
UNIDEN	EX4100	PP501 / HHRP501	TYPE 1
UNIDEN	EX4101	PP501 / HHRP501	TYPE 1
UNIDEN	EX4102	PP501 / HHRP501	TYPE 1
UNIDEN	EX4112	PP501 / HHRP501	TYPE 1
UNIDEN	EX422	HHRP802	TYPE 8
UNIDEN	EX442	HHRP801	TYPE 7
UNIDEN	EX4500	PP501 / HHRP501	TYPE 1
UNIDEN	EX4800	PP501 / HHRP501	TYPE 1
UNIDEN	EX500	PP501 / HHRP501	TYPE 1
UNIDEN	EX5000	PP501 / HHRP501	TYPE 1
UNIDEN	EX6000		NOT AVAILABLE
UNIDEN	EX7000	PP501 / HHRP501	TYPE 1
UNIDEN	EX7500	PP501 / HHRP501	TYPE 1
UNIDEN	EX7700	PP501 / HHRP501	TYPE 1
UNIDEN	EX8050	PP501 / HHRP501	TYPE 1
UNIDEN	EX900	PP501 / HHRP501	TYPE 1
UNIDEN	EX901		NOT AVAILABLE
UNIDEN	EX902	PP501 / HHRP501	TYPE 1
UNIDEN	EX905	HHRP40SC1B	DISCONTINUED

Vendor	Phone Model #	Battery Sku	Battery Description
UNIDEN	EX915	PP501 / HHRP501	TYPE 1
UNIDEN	EX917	PP301 / HHRP301	TYPE 2
UNIDEN	EX925	PP501 / HHRP501	TYPE 1
UNIDEN	EX945	PP501 / HHRP501	TYPE 1
UNIDEN	EX95	HHRP40SC1B	DISCONTINUED
UNIDEN	EX965	PP501 / HHRP501	TYPE 1
UNIDEN	EXA-2245	PP501 / HHRP501	TYPE 1
UNIDEN	EXA2950	PP501 / HHRP501	TYPE 1
UNIDEN	EXA3955	PP501 / HHRP501	TYPE 1
UNIDEN	EXA7950	PP501 / HHRP501	TYPE 1
UNIDEN	EXA8955	PP501 / HHRP501	TYPE 1
UNIDEN	EXA915	PP501 / HHRP501	TYPE 1
UNIDEN	EXA918	PP501 / HHRP501	TYPE 1
UNIDEN	EXA950	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI2248	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI2950	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI2980I	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI378	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI3985	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI7248A	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI7960I	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI7980	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI7980I	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI7980B	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI8985	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI918	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI9181	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI91B	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI985HS	PP501 / HHRP501	TYPE 1
UNIDEN	EXAI98D	PP501 / HHRP501	TYPE 1
UNIDEN	EXI1980	PP501 / HHRP501	TYPE 1
UNIDEN	EXI2246	PP501 / HHRP501	TYPE 1
UNIDEN	EXI2926	PP501 / HHRP501	TYPE 1
UNIDEN	EXI2960	PP501 / HHRP501	TYPE 1
UNIDEN	EXI2965	PP501 / HHRP501	TYPE 1
UNIDEN	EXI3226	PP501 / HHRP501	TYPE 1
UNIDEN	EXI376	PP501 / HHRP501	TYPE 1
UNIDEN	EXI3965	PP501 / HHRP501	TYPE 1
UNIDEN	EXI7926	PP501 / HHRP501	TYPE 1
UNIDEN	EXI7950	PP501 / HHRP501	TYPE 1
UNIDEN	EXI7960	PP501 / HHRP501	TYPE 1
UNIDEN	EXI8600A	PP501 / HHRP501	TYPE 1
UNIDEN	EXI8965	PP501 / HHRP501	TYPE 1
UNIDEN	EXI8966	PP501 / HHRP501	TYPE 1
UNIDEN	EXI916	PP501 / HHRP501	TYPE 1
UNIDEN	EXI917	PP501 / HHRP501	TYPE 1
UNIDEN	EXI91S	PP501 / HHRP501	TYPE 1
UNIDEN	EXI960	PP501 / HHRP501	TYPE 1
UNIDEN	EXI975	PP501 / HHRP501	TYPE 1
UNIDEN	EXI976A	PP501 / HHRP501	TYPE 1
UNIDEN	EXI976CA	PP501 / HHRP501	TYPE 1

Vendor	Phone Model #	Battery Sku	Battery Description
UNIDEN	EXL8900	PP501 / HHRP501	TYPE 1
UNIDEN	EXL8901	PP501 / HHRP501	TYPE 1
UNIDEN	EXL8945	PP501 / HHRP501	TYPE 1
UNIDEN	EXLA8950	PP501 / HHRP501	TYPE 1
UNIDEN	EXLA8962	PP501 / HHRP501	TYPE 1
UNIDEN	EXLI8962	PP501 / HHRP501	TYPE 1
UNIDEN	EXP2240	PP501 / HHRP501	TYPE 1
UNIDEN	EXP2241	PP501 / HHRP501	TYPE 1
UNIDEN	EXP2243		NOT AVAILABLE
UNIDEN	EXP2800	PP501 / HHRP501	TYPE 1
UNIDEN	EXP2900	PP501 / HHRP501	TYPE 1
UNIDEN	EXP2901	PP501 / HHRP501	TYPE 1
UNIDEN	EXP2903	PP501 / HHRP501	TYPE 1
UNIDEN	EXP2926	PP501 / HHRP501	TYPE 1
UNIDEN	EXP3241A	PP501 / HHRP501	TYPE 1
UNIDEN	EXP370		NOT AVAILABLE
UNIDEN	EXP371		NOT AVAILABLE
UNIDEN	EXP380B / L / P		NOT AVAILABLE
UNIDEN	EXP6900	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7241A	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7900	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7901	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7902	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7903	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7904	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7950	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7960	PP501 / HHRP501	TYPE 1
UNIDEN	EXP7980	PP501 / HHRP501	TYPE 1
UNIDEN	EXP900	HHRP40SC1B	DISCONTINUED
UNIDEN	EXP9005	PP501 / HHRP501	TYPE 1
UNIDEN	EXP901		NOT AVAILABLE
UNIDEN	EXP905	HHRP40SC1B	DISCONTINUED
UNIDEN	EXP91	PP501 / HHRP501	TYPE 1
UNIDEN	EXP9100		NOT AVAILABLE
UNIDEN	EXP9110		NOT AVAILABLE
UNIDEN	EXP91S	PP501 / HHRP501	TYPE 1
UNIDEN	EXP92	PP501 / HHRP501	TYPE 1
UNIDEN	EXP920	PP501 / HHRP501	TYPE 1
UNIDEN	EXP9200		NOT AVAILABLE
UNIDEN	EXP95	HHRP40SC1B	DISCONTINUED
UNIDEN	EXP9500		NOT AVAILABLE
UNIDEN	EXP950A	PP501 / HHRP501	TYPE 1
UNIDEN	EXP95I	HHRP40SC1B	DISCONTINUED
UNIDEN	EXP9550		NOT AVAILABLE
UNIDEN	EXP9580		NOT AVAILABLE
UNIDEN	EXP9586		NOT AVAILABLE
UNIDEN	EXP9590		NOT AVAILABLE
UNIDEN	EXP96	HHRP40SC1B	DISCONTINUED
UNIDEN	EXP9600		NOT AVAILABLE
UNIDEN	EXP97	PP501 / HHRP501	TYPE 1
UNIDEN	EXP9800		NOT AVAILABLE

Vendor	Phone Model #	Battery Sku	Battery Description
UNIDEN	EXP990		NOT AVAILABLE
UNIDEN	EXP9900	PP501 / HHRP501	TYPE 1
UNIDEN	EXP9966	PP501 / HHRP501	TYPE 1
UNIDEN	EXP9995	PP900	For V-Tech 900MHz
UNIDEN	EXP9996	PP900	For V-Tech 900MHz
UNIDEN	EXR2460		NOT AVAILABLE
UNIDEN	EXR2480		NOT AVAILABLE
UNIDEN	EXS2010	PP501 / HHRP501	TYPE 1
UNIDEN	EXS2050	PP501 / HHRP501	TYPE 1
UNIDEN	EXS2060	PP501 / HHRP501	TYPE 1
UNIDEN	EXS208	PP501 / HHRP501	TYPE 1
UNIDEN	EXS2080	PP501 / HHRP501	TYPE 1
UNIDEN	EXS2084	PP501 / HHRP501	TYPE 1
UNIDEN	EXS9005	PP501 / HHRP501	TYPE 1
UNIDEN	EXS9110		NOT AVAILABLE
UNIDEN	EXS9500		NOT AVAILABLE
UNIDEN	EXS9600		NOT AVAILABLE
UNIDEN	EXS9650		NOT AVAILABLE
UNIDEN	EXS9660		NOT AVAILABLE
UNIDEN	EXS9800		NOT AVAILABLE
UNIDEN	EXS9900	PP900	For V-Tech 900MHz
UNIDEN	EXS9910	PP900	For V-Tech 900MHz
UNIDEN	EXS9950	PP900	For V-Tech 900MHz
UNIDEN	EXS9960	PP900	For V-Tech 900MHz
UNIDEN	EXS9965	PP900	For V-Tech 900MHz
UNIDEN	EXS9966	PP900	For V-Tech 900MHz
UNIDEN	EXS9980	PP900	For V-Tech 900MHz
UNIDEN	EXS9995	PP900	For V-Tech 900MHz
UNIDEN	EXS9996	PP900	For V-Tech 900MHz
UNIDEN	EXT1365	PP501 / HHRP501	TYPE 1
UNIDEN	EXT1760	PP501 / HHRP501	TYPE 1
UNIDEN	EXT1865		NOT AVAILABLE
UNIDEN	EXT1960	PP900	For V-Tech 900MHz
UNIDEN	EXT1965	PP900	For V-Tech 900MHz
UNIDEN	EXV-98		NOT AVAILABLE
UNIDEN	EXV990	PP501 / HHRP501	TYPE 1
UNIDEN	QV4544	PP301 / HHRP301	TYPE 2
UNIDEN	QVA4505	PP301 / HHRP301	TYPE 2
UNIDEN	T121		NOT AVAILABLE
UNIDEN	TRU241	PP501 / HHRP501	TYPE 1
UNIDEN	TRU246	PP501 / HHRP501	TYPE 1
UNIDEN	TRU248	PP501 / HHRP501	TYPE 1
UNIDEN	TRU2485	PP501 / HHRP501	TYPE 1
UNIDEN	TRU341	PP501 / HHRP501	TYPE 1
UNIDEN	TRU3455	PP501 / HHRP501	TYPE 1
UNIDEN	TRU346	PP501 / HHRP501	TYPE 1
UNIDEN	TRU3465	PP501 / HHRP501	TYPE 1
UNIDEN	TRU3466	PP501 / HHRP501	TYPE 1
UNIDEN	TRU348	PP501 / HHRP501	TYPE 1
UNIDEN	TRU3485	PP501 / HHRP501	TYPE 1
UNIDEN	TRU446	HHRP546	

Vendor	Phone Model #	Battery Sku	Battery Description
UNIDEN	TRU446-2	HHRP546	
UNIDEN	TRU4465	HHRP546	
UNIDEN	TRU4465-2	HHRP546	
UNIDEN	TRU4485	HHRP546	
UNIDEN	TRU4485-2	HHRP546	
UNIDEN	TRU488	HHRP546	
UNIDEN	TRU488-2	HHRP546	
UNIDEN	TRU546	PP501 / HHRP501	TYPE 1
UNIDEN	TRU548	PP501 / HHRP501	TYPE 1
UNIDEN	TRU5865	HHRP546	
UNIDEN	TRU5865-2	HHRP546	
UNIDEN	TRU5885	HHRP546	
UNIDEN	TRU5885-2	HHRP546	
UNIDEN	TXC400	HHRP546	
UNIDEN	TXC580	HHRP546	
UNIDEN	XA16980	PP501 / HHRP501	TYPE 1
UNIDEN	XC-15	PP301 / HHRP301	TYPE 2
UNIDEN	XC1660	PP302 / HHRP302	TYPE 3
UNIDEN	XC1665	PP301 / HHRP301	TYPE 2
UNIDEN	XC1667	PP301 / HHRP301	TYPE 2
UNIDEN	XC265	PP301 / HHRP301	TYPE 2
UNIDEN	XC301	PP301 / HHRP301	TYPE 2
UNIDEN	XC302	PP301 / HHRP301	TYPE 2
UNIDEN	XC305	PP301 / HHRP301	TYPE 2
UNIDEN	XC310	PP301 / HHRP301	TYPE 2
UNIDEN	XC310G	PP301 / HHRP301	TYPE 2
UNIDEN	XC312	PP301 / HHRP301	TYPE 2
UNIDEN	XC314	PP301 / HHRP301	TYPE 2
UNIDEN	XC315	PP301 / HHRP301	TYPE 2
UNIDEN	XC320	PP301 / HHRP301	TYPE 2
UNIDEN	XC330	PP301 / HHRP301	TYPE 2
UNIDEN	XC340	PP301 / HHRP301	TYPE 2
UNIDEN	XC345	PP301 / HHRP301	TYPE 2
UNIDEN	XC3510	PP301 / HHRP301	TYPE 2
UNIDEN	XC3514	PP301 / HHRP301	TYPE 2
UNIDEN	XC3515	PP301 / HHRP301	TYPE 2
UNIDEN	XC351Y	PP301 / HHRP301	TYPE 2
UNIDEN	XC3530	PP301 / HHRP301	TYPE 2
UNIDEN	XC3545	PP301 / HHRP301	TYPE 2
UNIDEN	XC355		NOT AVAILABLE
UNIDEN	XC365	PP301 / HHRP301	TYPE 2
UNIDEN	XC4519	PP301 / HHRP301	TYPE 2
UNIDEN	XC4534	PP301 / HHRP301	TYPE 2
UNIDEN	XC600	PP301 / HHRP301	TYPE 2
UNIDEN	XC610	PP301 / HHRP301	TYPE 2
UNIDEN	XC611	PP301 / HHRP301	TYPE 2
UNIDEN	XC615	PP301 / HHRP301	TYPE 2
UNIDEN	XC645	PP301 / HHRP301	TYPE 2
UNIDEN	XC645C	PP301 / HHRP301	TYPE 2
UNIDEN	XC6450	PP301 / HHRP301	TYPE 2
UNIDEN	XC660	PP301 / HHRP301	TYPE 2

Vendor	Phone Model #	Battery Sku	Battery Description
UNIDEN	XC700	PP301 / HHRP301	TYPE 2
UNIDEN	XC714	PP301 / HHRP301	TYPE 2
UNIDEN	XC716	PP301 / HHRP301	TYPE 2
UNIDEN	XC717	PP301 / HHRP301	TYPE 2
UNIDEN	XC718	PP301 / HHRP301	TYPE 2
UNIDEN	XC810		NOT AVAILABLE
UNIDEN	XC815		NOT AVAILABLE
UNIDEN	XCA2500	PP301 / HHRP301	TYPE 2
UNIDEN	XCA2510	PP301 / HHRP301	TYPE 2
UNIDEN	XCA2515	PP301 / HHRP301	TYPE 2
UNIDEN	XCA4500	PP301 / HHRP301	TYPE 2
UNIDEN	XCA4510	PP301 / HHRP301	TYPE 2
UNIDEN	XCA4515	PP301 / HHRP301	TYPE 2
UNIDEN	XCA550		NOT AVAILABLE
UNIDEN	XCA555		NOT AVAILABLE
UNIDEN	XCA556	PP301 / HHRP301	TYPE 2
UNIDEN	XCA650	PP301 / HHRP301	TYPE 2
UNIDEN	XCA660	PP301 / HHRP301	TYPE 2
UNIDEN	XCA680	PP301 / HHRP301	TYPE 2
UNIDEN	XCAI680	PP301 / HHRP301	TYPE 2
UNIDEN	XCI607	PP301 / HHRP301	TYPE 2
UNIDEN	XCI660	PP301 / HHRP301	TYPE 2
UNIDEN	XCI665	PP301 / HHRP301	TYPE 2
UNIDEN	XCI667	PP301 / HHRP301	TYPE 2
UNIDEN	XE200	HHRP801	TYPE 7
UNIDEN	XE250	HHRP802	TYPE 8
UNIDEN	XE300	HHRP801	TYPE 7
UNIDEN	XE350	HHRP802	TYPE 8
UNIDEN	XE355	PP301 / HHRP301	TYPE 2
UNIDEN	XE360	HHRP801C1B	TYPE 7
UNIDEN	XE365	PP301 / HHRP301	TYPE 2
UNIDEN	XE400	HHRP801	TYPE 7
UNIDEN	XE422S	HHRP802	TYPE 8
UNIDEN	XE442	HHRP802	TYPE 8
UNIDEN	XE500	HHRP801	TYPE 7
UNIDEN	XE550	HHRP801	TYPE 7
UNIDEN	XE570	HHRP802	TYPE 8
UNIDEN	XE660	PP301 / HHRP301	TYPE 2
UNIDEN	XE665	PP301 / HHRP301	TYPE 2
UNIDEN	XE667	PP301 / HHRP301	TYPE 2
UNIDEN	XE700	HHRP801	TYPE 7
UNIDEN	XE777	HHRP802	TYPE 8
UNIDEN	XE777S	HHRP802	TYPE 8
UNIDEN	XE785	PP301 / HHRP301	TYPE 2
UNIDEN	XE895	PP501 / HHRP501	TYPE 1
UNIDEN	XE985	PP501 / HHRP501	TYPE 1
V-TECH	1064	PP302 / HHRP302	TYPE 3
V-TECH	1064XL	PP302 / HHRP302	TYPE 3
V-TECH	1261	HHRP290	
V-TECH	1932	PP900	for V-Tech 900MHz

Vendor	Phone Model #	Battery Sku	Battery Description
V-TECH	1962	PP900	for V-Tech 900MHz
V-TECH	80-4134-00-00	PP900	for V-Tech 900MHz
V-TECH	80-4280-00-00	PP900	for V-Tech 900MHz
V-TECH	80-5017-00-00		NOT AVAILABLE
V-TECH	80-5071-00-00		NOT AVAILABLE
V-TECH	80-5074-00-00	PP303 / HHRP303	TYPE 4
V-TECH	905NDL		NOT AVAILABLE
V-TECH	9060i	PP900	for V-Tech 900MHz
V-TECH	9108	PP900	for V-Tech 900MHz
V-TECH	9109	PP303 / HHRP303	TYPE 4
V-TECH	910ADL	PP900	for V-Tech 900MHz
V-TECH	910VDL	PP900	for V-Tech 900MHz
V-TECH	9121	PP900	for V-Tech 900MHz
V-TECH	912ADL	PP900	for V-Tech 900MHz
V-TECH	912ADLC	PP900	for V-Tech 900MHz
V-TECH	914ADL	PP900	for V-Tech 900MHz
V-TECH	914ADLi	PP900	for V-Tech 900MHz
V-TECH	914AKLi	PP900	for V-Tech 900MHz
V-TECH	914ITAD	PP900	for V-Tech 900MHz
V-TECH	9155	PP900	for V-Tech 900MHz
V-TECH	915ADL	PP900	for V-Tech 900MHz
V-TECH	915AKL	PP900	for V-Tech 900MHz
V-TECH	916ADL	PP900	for V-Tech 900MHz
V-TECH	916ADLi	PP900	for V-Tech 900MHz
V-TECH	917ADX	PP900	for V-Tech 900MHz
V-TECH	918ADX	PP900	for V-Tech 900MHz
V-TECH	920ADL	PP900	for V-Tech 900MHz
V-TECH	921ADL	PP900	for V-Tech 900MHz
V-TECH	EV2650	4-AAA NIMH	
V-TECH	HJ-VT1920C	PP900	for V-Tech 900MHz
V-TECH	HJ-VT1930C	PP900	for V-Tech 900MHz
V-TECH	HJ-VT1970C	PP900	for V-Tech 900MHz
V-TECH	IP5850	HHR3SPA2B	2 'AA' NiMH
V-TECH	IP5825	HHR3SPA2B	2 'AA' NiMH
V-TECH	VT00-1921	PP900	for V-Tech 900MHz
V-TECH	VT9109	PP303 / HHRP303	TYPE 4
V-TECH	VT9118	PP303 / HHRP303	TYPE 4
V-TECH	VT 9125		NOT AVAILABLE
V-TECH	VT01-9111	PP900	for V-Tech 900MHz
V-TECH	VT02-9111	PP900	for V-Tech 900MHz
V-TECH	VT03-9111	PP900	for V-Tech 900MHz
V-TECH	VT1711	PP900	for V-Tech 900MHz
V-TECH	VT1721	PP900	for V-Tech 900MHz
V-TECH	VT1731	PP900	for V-Tech 900MHz
V-TECH	VT1733	PP900	for V-Tech 900MHz
V-TECH	VT1900	PP900	for V-Tech 900MHz
V-TECH	VT1901	PP900	for V-Tech 900MHz
V-TECH	VT1901C	PP900	for V-Tech 900MHz
V-TECH	VT1902C		NOT AVAILABLE
V-TECH	VT1910C	PP900	for V-Tech 900MHz
V-TECH	VT1911	PP900	for V-Tech 900MHz

<b>Vendor</b>	<b>Phone Model #</b>	<b>Battery Sku</b>	<b>Battery Description</b>
V-TECH	VT1917		NOT AVAILABLE
V-TECH	VT1920	PP900	for V-Tech 900MHz
V-TECH	VT1920C	PP900	for V-Tech 900MHz
V-TECH	VT1921	PP900	for V-Tech 900MHz
V-TECH	VT1922	PP900	for V-Tech 900MHz
V-TECH	VT1930C	PP900	for V-Tech 900MHz
V-TECH	VT1930CX	PP900	for V-Tech 900MHz
V-TECH	VT1932	PP900	for V-Tech 900MHz
V-TECH	VT1940	PP900	for V-Tech 900MHz
V-TECH	VT1961CI	PP900	for V-Tech 900MHz
V-TECH	VT1962	PP900	for V-Tech 900MHz
V-TECH	VT1970	PP900	for V-Tech 900MHz
V-TECH	VT1970CI	PP900	for V-Tech 900MHz
V-TECH	VT2121	HHRP303	
V-TECH	VT2408	HHRP303	
V-TECH	VT2418		NOT AVAILABLE
V-TECH	VT2420	HHRP290	
V-TECH	VT2421	HHRP290	
V-TECH	VT2422	HHRP290	
V-TECH	VT2425	HHRP290	
V-TECH	VT2429	HHRP303	
V-TECH	VT2430	HHRP290	
V-TECH	VT2431	HHRP290	
V-TECH	VT2433	HHRP290	
V-TECH	VT2460	HHRP290	
V-TECH	VT2461	HHRP290	
V-TECH	VT2467	HHRP290	
V-TECH	VT2480	HHRP290	
V-TECH	VT2481	HHRP290	
V-TECH	VT2489	HHRP290	
V-TECH	VT2498	HHRP303	
V-TECH	VT2528	HHRP303	
V-TECH	VT2621	HHRP290	
V-TECH	VT2652	HHRP290	
V-TECH	VT2910	PP900	for V-Tech 900MHz
V-TECH	VT2910C	PP900	for V-Tech 900MHz
V-TECH	VT2920C	PP900	for V-Tech 900MHz
V-TECH	VT2931	PP900	for V-Tech 900MHz
V-TECH	VT2932	PP900	for V-Tech 900MHz
V-TECH	VT2950CI	PP900	for V-Tech 900MHz
V-TECH	VT2960	PP900	for V-Tech 900MHz
V-TECH	VT2960CI	PP900	for V-Tech 900MHz
V-TECH	VT2960HJ	PP900	for V-Tech 900MHz
V-TECH	VT2961	PP900	for V-Tech 900MHz
V-TECH	VT2962	PP900	for V-Tech 900MHz
V-TECH	VT5801	HHRP290	
V-TECH	VT5820	HHRP290	
V-TECH	VT5831	HHRP290	
V-TECH	VT5836	HHRP290	
V-TECH	VT5881	HHRP290	
V-TECH	VT5886	HHRP290	

Vendor	Phone Model #	Battery Sku	Battery Description
V-TECH	VT5888	HHRP290	
V-TECH	VT5889	HHRP290	
V-TECH	VT00-2421	HHRP290	
V-TECH	VT20-2420	HHRP290	
V-TECH	VT20-2431	HHRP290	
V-TECH	VT20-2432	HHRP290	
V-TECH	VT20-2437	HHRP290	
V-TECH	VT20-2439	HHRP290	
V-TECH	VT20-2481	HHRP290	
V-TECH	VT62-9111	PP900	for V-Tech 900MHz
V-TECH	VT64-9116		NOT AVAILABLE
V-TECH	VT66-9116		NOT AVAILABLE
V-TECH	VT80-5017-00-00	HHRP290	
V-TECH	VT80-5216-00-00	HHRP290	
V-TECH	VT81-9111	PP900	for V-Tech 900MHz
V-TECH	VT9000	PP900	for V-Tech 900MHz
V-TECH	VT9060	PP900	for V-Tech 900MHz
V-TECH	VT9060i	PP900	for V-Tech 900MHz
V-TECH	VT9080		NOT AVAILABLE
V-TECH	VT9105	PP900	for V-Tech 900MHz
V-TECH	VT9108	PP900	for V-Tech 900MHz
V-TECH	VT9109	PP303 / HHRP303	TYPE 4
V-TECH	VT9111	PP900	for V-Tech 900MHz
V-TECH	VT9112	PP900	for V-Tech 900MHz
V-TECH	VT9115	PP900	for V-Tech 900MHz
V-TECH	VT9117	PP303 / HHRP303	TYPE 4
V-TECH	VT9118	PP303 / HHRP303	TYPE 4
V-TECH	VT9121	PP900	for V-Tech 900MHz
V-TECH	VT9122	PP303 / HHRP303	TYPE 4
V-TECH	VT9123	PP303 / HHRP303	TYPE 4
V-TECH	VT9125	PP900	for V-Tech 900MHz
V-TECH	VT9141	PP900	for V-Tech 900MHz
V-TECH	VT9151	PP900	for V-Tech 900MHz
V-TECH	VT9155	PP900	for V-Tech 900MHz
V-TECH	VT9161	PP303 / HHRP303	TYPE 4
V-TECH	VT920ADL	PP900	for V-Tech 900MHz
V-TECH	VT921ADL	PP900	for V-Tech 900MHz
V-TECH	VT9241	PP900	for V-Tech 900MHz
V-TECH	VT2420		NOT AVAILABLE
V-TECH	VT2428		NOT AVAILABLE
V-TECH	VT2430		NOT AVAILABLE
V-TECH	VT2431		NOT AVAILABLE
V-TECH	VT2461		NOT AVAILABLE
V-TECH	VT2468		NOT AVAILABLE
V-TECH	VT2481		NOT AVAILABLE
V-TECH	VT5820		NOT AVAILABLE
V-TECH	VT5831		NOT AVAILABLE
V-TECH	VT61-9126		NOT AVAILABLE
V-TECH	VT61-9126IN		NOT AVAILABLE
V-TECH	VT63-9111HJ		NOT AVAILABLE
V-TECH	VT9122 Square Series	PP303 / HHRP303	TYPE 4